

AMX DRIVER V1.0

FOR MIRAGE DIGITAL AMPLIFIER

COMPATIBLE WITH



AMX

MIRAGE

Overview

The Autonomic AMX version 1.0 driver for the Mirage digital amplifier, models M-800 and M-400, is compatible with all recent versions of AMX and all versions of the Autonomic Mirage digital amplifier firmware.

Autonomic Mirage digital amplifiers offer scalable multi-zone amplification with 100 watts per zone. Each zone is individually controllable from an AMX system using the Autonomic AMX driver.

The M-400 and M-800 digital amplifiers can be mixed in any configuration and stacked up to 96 zones, providing an 8 source x 96 zone matrix (M-800s) or a 6 source x 96 zone matrix (M-400s). The driver offers full control over all aspects of a Mirage amp stack of any size.

This driver was developed and tested with Netlinx 4.1.1204 against an NI-2100 running Netlinx v4.1.373 and TP4Design 3.3.0 against an MXT-1000 running firmware v2.104.28 but is compatible with any NI series processor and any G4 and G5 panel.

Features

Each zone of a Mirage amplifier is individually controllable and has many features. The Autonomic AMX v1.0 driver offers full control over the complete feature set per zone, from basic control like volume & mute, power, and source selection to advanced functionality like max volume, mono vs. stereo, power on volume, bass, treble, balance, gain, and loudness.

Downloading the Driver

All Mirage digital amplifier control drivers are available on our Downloads page, found at

http://www.autonomic-controls.com/support_downloads.php.

To download the AMX v1.0 driver, simply click on the link labeled **AMX Amp Driver v1.0** to start the download of the zip file.

Inside the download:

- Compressed sample program (Netlinx exported workspace)
- Standalone driver file
- Touch panel file (for MXT-1000)
- Autonomic Programming Guide: AMX driver v1.0 for Mirage Digital Amplifier

The screenshot shows the Autonomic website's Downloads page. At the top, there's a navigation bar with links for DEALER LOGIN, REGISTER, SUBSCRIBE, and social media icons for Twitter and Facebook. Below the navigation is a banner featuring several control modules (e.g., tablets, phones) with the text "Converge with a higher standard." A large "Downloads" button is prominently displayed. To the left of the main content area, there's a sidebar with links for Documentation, Downloads, and Support FAQ. The main content area is divided into sections for different products:

- Downloads**: Includes links for "Mirage Media Controller (MMC) for iPad, iPhone/iPod Touch, and Android Phones". It notes that mobile apps require a "Mirage Media Server". Below this are links for "Mirage Media Controller for iPad", "Mirage Media Controller for iPhone/iPod Touch", and "Mirage Media Controller for Android Phones".
- AMX**: Includes a link for "AMX MMS Module 4.5.4 (.zip)" with a note: "(Note: For the AMX Module to work, you must have at least MMS firmware version 4.5.13281.0)".
- Bitwise**: Includes a link for "Bitwise MMS Module (link)".
- Command Fusion**: Includes a link for "Command Fusion MMS Module (link)".
- Control4**: Includes a link for "Control4 MMS Driver 3.0 (.zip)" with a note: "(Note: This driver fully supports Control4 OS 2.6)".

On the right side of the page, there's a "Signed up yet?" section with a form for entering an email address and a "SUBMIT" button. Below that is a section for the "Mirage MMS-5A" streamer, featuring its logo and a "The Multi-room Audiophile Streamer" tagline. At the bottom of the page, there's a "Introduction to Mirage Media Server" section with a video thumbnail and a "Available on the" link.

Converge with a higher standard.

Configuration

The module supports a panel array. This allows multiple panels to control one instance of the module. This configuration reduces resource utilization on the processor. A panel array is simply a device array containing panel devices. If the main program contains three panel devices, dvTP1, dvTP2, and dvTP3, the panel array to include all three would look like:

```
dev dvTP_Array = { dvTP1, dvTP2, dvTP3 }
```

To set the sample program up, make sure you have the latest versions of Netlinx Studio and TP4Design. Both are available from the AMX website under Development Tools (<http://www.amx.com/products/categoryDevelopmentTools.asp>).

Once those programs are installed, simply open the Netlinx workspace included in the download.

Start by setting the IP address of the amp stack by changing the value of **AMP_IP_ADDRESS**. Configure the panel to match the device ID in the program. This is **10001:5:0** by default. **It's important to note that channel 1 on the virtual device must be held on for the duration control is required.**

```
on[vdvAmp, 1]
```

Defining the module

To use this module in a full program, add a definition of our module to the main program. That configuration looks like the below code snippet.

```
DEFINE_DEVICE
dvAmp = 0:FIRST_LOCAL_PORT:0
dvTP1 = 10001:5:0
dvTP2 = 10002:5:0
dvTP3 = 10003:5:0
vdvAmp = 33001:1:0 // the virtual device that represents the
connection of the amp stack

DEFINE_VARIABLE
char AMP_IP_ADDRESS[] = '192.168.1.54' // for example, replace
with the IP of the amp stack
integer AMP_CONTROL_PORT = 17037
dev dvTP_Array[] = { dvTP1, dvTP2, dvTP3 }

DEFINE_MODULE 'Autonomic Mirage Amp' ACAMP (vdvAmp, dvAmp,
dvTP_Array, AMP_IP_ADDRESS, AMP_CONTROL_PORT)
```

Programming

Due to the number of zones and the functionality offered per zone, the module has to make use of channels well above the default maximum channel of 255. The program should set virtual channel and level counts for the virtual device that is the amp. We recommend a virtual channel count of 4000 and a virtual level count of 1000. Do this at program start like the below code snippet.

```
SET_VIRTUAL_CHANNEL_COUNT(vdvAmp, 4000)
SET_VIRTUAL_LEVEL_COUNT(vdvAmp, 1000)
```

Calculating Channels for Zones

Each zone is identically programmed. See the [appendix](#) at the end of this document for an explanation of the formula used to calculate the values and a table of the channel and level values for all 96 zones.

Control Channels

Certain, more global, actions are controlled using channels on the virtual device itself.

Channel 1

- on = connect
on[vdvAmp, 1]
- off = disconnect
off[vdvAmp, 1]

Channel 2

- on = turn protocol communications logging on
on[vdvAmp, 2]
- off = turn protocol communications logging off
off[vdvAmp, 2]

Channel 3

- on = turn parsed (human readable) communications logging on
on[vdvAmp, 3]
- off = turn parsed (human readable) communications logging off
off[vdvAmp, 3]

Channel 4

- on = turn all zones off
on[vdvAmp, 4]
- This channel will turn itself off and should be pulsed.

Technical Support

If you require further assistance with configuring the AMX driver v1.0 for the Mirage Digital Amplifier, please contact Autonomic Technical Support at +1 914-598-1647 option 2, or email support@autonomic-controls.com. You can also visit the Autonomic Knowledgebase (<http://www.autonomic-controls.com/kb>) for troubleshooting information and access to submitting a support ticket.

Appendix: Channel and Level Values

All target channels are calculated using a **ZONE_OFFSET** value of 40 except for levels that use a **ZONE_LVL_OFFSET** value of 10. Zone 1 shares its channels with the initial channel values. A button programmed to toggle power on Zone 1 should use channel 10. The formula for calculating channels for other zones is

```
(initialChannel|initialLevel + (ZONE_OFFSET|ZONE_LVL_  
OFFSET * (zone - 1)))
```

Therefore, a button programmed to toggle power on Zone 67 would use channel **(10 + (40 * (67 - 1)))** or channel 2650. A bar graph attached to the volume level for Zone 1 would use level 1. The volume bar graph for Zone 67 would use level **((1 + (10 * (67 - 1)))** or 661.

For convenience, the following pages contain a table with all channel and level values for zones 1–96.

Function	Channel/Level
Zone 1 Power Toggle	10
Zone 1 Power On	38
Zone 1 Power Off	39
Zone 1 Mute Toggle	11
Zone 1 Mute On	40
Zone 1 Mute Off	41
Zone 1 Volume Up	12
Zone 1 Volume Down	13
Zone 1 Bass Up	23
Zone 1 Bass Down	24
Zone 1 Treble Up	25
Zone 1 Treble Down	26
Zone 1 Gain Up	27
Zone 1 Gain Down	28
Zone 1 Power On Volume Up	29
Zone 1 Power On Volume Down	30
Zone 1 Balance Left	31
Zone 1 Balance Right	32
Zone 1 Max Volume Up	33
Zone 1 Max Volume Down	34
Zone 1 Loudness Toggle	35
Zone 1 Power On Volume Toggle	36
Zone 1 Mono/Stereo Toggle	37
Zone 1 Source 1 Select	15
Zone 1 Source 2 Select	16
Zone 1 Source 3 Select	17
Zone 1 Source 4 Select	18
Zone 1 Source 5 Select	19
Zone 1 Source 6 Select	20
Zone 1 Source 7 Select	21
Zone 1 Source 8 Select	22
Zone 1 Volume Level	1
Zone 1 Bass Level	2
Zone 1 Treble Level	3
Zone 1 Gain Level	4
Zone 1 Power On Volume Level	5
Zone 1 Balance Level	6
Zone 1 Max Volume Level	7
Zone 1 Zone Name	14

Function	Channel/Level
Zone 2 Power Toggle	50
Zone 2 Power On	78
Zone 2 Power Off	79
Zone 2 Mute Toggle	51
Zone 2 Mute On	80
Zone 2 Mute Off	81
Zone 2 Volume Up	52
Zone 2 Volume Down	53
Zone 2 Bass Up	63
Zone 2 Bass Down	64
Zone 2 Treble Up	65
Zone 2 Treble Down	66
Zone 2 Gain Up	67
Zone 2 Gain Down	68
Zone 2 Power On Volume Up	69
Zone 2 Power On Volume Down	70
Zone 2 Balance Left	71
Zone 2 Balance Right	72
Zone 2 Max Volume Up	73
Zone 2 Max Volume Down	74
Zone 2 Loudness Toggle	75
Zone 2 Power On Volume Toggle	76
Zone 2 Mono/Stereo Toggle	77
Zone 2 Source 1 Select	55
Zone 2 Source 2 Select	56
Zone 2 Source 3 Select	57
Zone 2 Source 4 Select	58
Zone 2 Source 5 Select	59
Zone 2 Source 6 Select	60
Zone 2 Source 7 Select	61
Zone 2 Source 8 Select	62
Zone 2 Volume Level	11
Zone 2 Bass Level	12
Zone 2 Treble Level	13
Zone 2 Gain Level	14
Zone 2 Power On Volume Level	15
Zone 2 Balance Level	16
Zone 2 Max Volume Level	17
Zone 2 Zone Name	54

Function	Channel/Level
Zone 3 Power Toggle	90
Zone 3 Power On	118
Zone 3 Power Off	119
Zone 3 Mute Toggle	91
Zone 3 Mute On	120
Zone 3 Mute Off	121
Zone 3 Volume Up	92
Zone 3 Volume Down	93
Zone 3 Bass Up	103
Zone 3 Bass Down	104
Zone 3 Treble Up	105
Zone 3 Treble Down	106
Zone 3 Gain Up	107
Zone 3 Gain Down	108
Zone 3 Power On Volume Up	109
Zone 3 Power On Volume Down	110
Zone 3 Balance Left	111
Zone 3 Balance Right	112
Zone 3 Max Volume Up	113
Zone 3 Max Volume Down	114
Zone 3 Loudness Toggle	115
Zone 3 Power On Volume Toggle	116
Zone 3 Mono/Stereo Toggle	117
Zone 3 Source 1 Select	95
Zone 3 Source 2 Select	96
Zone 3 Source 3 Select	97
Zone 3 Source 4 Select	98
Zone 3 Source 5 Select	99
Zone 3 Source 6 Select	100
Zone 3 Source 7 Select	101
Zone 3 Source 8 Select	102
Zone 3 Volume Level	21
Zone 3 Bass Level	22
Zone 3 Treble Level	23
Zone 3 Gain Level	24
Zone 3 Power On Volume Level	25
Zone 3 Balance Level	26
Zone 3 Max Volume Level	27
Zone 3 Zone Name	94

Function	Channel/Level
Zone 4 Power Toggle	130
Zone 4 Power On	158
Zone 4 Power Off	159
Zone 4 Mute Toggle	131
Zone 4 Mute On	160
Zone 4 Mute Off	161
Zone 4 Volume Up	132
Zone 4 Volume Down	133
Zone 4 Bass Up	143
Zone 4 Bass Down	144
Zone 4 Treble Up	145
Zone 4 Treble Down	146
Zone 4 Gain Up	147
Zone 4 Gain Down	148
Zone 4 Power On Volume Up	149
Zone 4 Power On Volume Down	150
Zone 4 Balance Left	151
Zone 4 Balance Right	152
Zone 4 Max Volume Up	153
Zone 4 Max Volume Down	154
Zone 4 Loudness Toggle	155
Zone 4 Power On Volume Toggle	156
Zone 4 Mono/Stereo Toggle	157
Zone 4 Source 1 Select	135
Zone 4 Source 2 Select	136
Zone 4 Source 3 Select	137
Zone 4 Source 4 Select	138
Zone 4 Source 5 Select	139
Zone 4 Source 6 Select	140
Zone 4 Source 7 Select	141
Zone 4 Source 8 Select	142
Zone 4 Volume Level	31
Zone 4 Bass Level	32
Zone 4 Treble Level	33
Zone 4 Gain Level	34
Zone 4 Power On Volume Level	35
Zone 4 Balance Level	36
Zone 4 Max Volume Level	37
Zone 4 Zone Name	134

Function	Channel/Level
Zone 5 Power Toggle	170
Zone 5 Power On	198
Zone 5 Power Off	199
Zone 5 Mute Toggle	171
Zone 5 Mute On	200
Zone 5 Mute Off	201
Zone 5 Volume Up	172
Zone 5 Volume Down	173
Zone 5 Bass Up	183
Zone 5 Bass Down	184
Zone 5 Treble Up	185
Zone 5 Treble Down	186
Zone 5 Gain Up	187
Zone 5 Gain Down	188
Zone 5 Power On Volume Up	189
Zone 5 Power On Volume Down	190
Zone 5 Balance Left	191
Zone 5 Balance Right	192
Zone 5 Max Volume Up	193
Zone 5 Max Volume Down	194
Zone 5 Loudness Toggle	195
Zone 5 Power On Volume Toggle	196
Zone 5 Mono/Stereo Toggle	197
Zone 5 Source 1 Select	175
Zone 5 Source 2 Select	176
Zone 5 Source 3 Select	177
Zone 5 Source 4 Select	178
Zone 5 Source 5 Select	179
Zone 5 Source 6 Select	180
Zone 5 Source 7 Select	181
Zone 5 Source 8 Select	182
Zone 5 Volume Level	41
Zone 5 Bass Level	42
Zone 5 Treble Level	43
Zone 5 Gain Level	44
Zone 5 Power On Volume Level	45
Zone 5 Balance Level	46
Zone 5 Max Volume Level	47
Zone 5 Zone Name	174

Function	Channel/Level
Zone 6 Power Toggle	210
Zone 6 Power On	238
Zone 6 Power Off	239
Zone 6 Mute Toggle	211
Zone 6 Mute On	240
Zone 6 Mute Off	241
Zone 6 Volume Up	212
Zone 6 Volume Down	213
Zone 6 Bass Up	223
Zone 6 Bass Down	224
Zone 6 Treble Up	225
Zone 6 Treble Down	226
Zone 6 Gain Up	227
Zone 6 Gain Down	228
Zone 6 Power On Volume Up	229
Zone 6 Power On Volume Down	230
Zone 6 Balance Left	231
Zone 6 Balance Right	232
Zone 6 Max Volume Up	233
Zone 6 Max Volume Down	234
Zone 6 Loudness Toggle	235
Zone 6 Power On Volume Toggle	236
Zone 6 Mono/Stereo Toggle	237
Zone 6 Source 1 Select	215
Zone 6 Source 2 Select	216
Zone 6 Source 3 Select	217
Zone 6 Source 4 Select	218
Zone 6 Source 5 Select	219
Zone 6 Source 6 Select	220
Zone 6 Source 7 Select	221
Zone 6 Source 8 Select	222
Zone 6 Volume Level	51
Zone 6 Bass Level	52
Zone 6 Treble Level	53
Zone 6 Gain Level	54
Zone 6 Power On Volume Level	55
Zone 6 Balance Level	56
Zone 6 Max Volume Level	57
Zone 6 Zone Name	214

Function	Channel/Level
Zone 7 Power Toggle	250
Zone 7 Power On	278
Zone 7 Power Off	279
Zone 7 Mute Toggle	251
Zone 7 Mute On	280
Zone 7 Mute Off	281
Zone 7 Volume Up	252
Zone 7 Volume Down	253
Zone 7 Bass Up	263
Zone 7 Bass Down	264
Zone 7 Treble Up	265
Zone 7 Treble Down	266
Zone 7 Gain Up	267
Zone 7 Gain Down	268
Zone 7 Power On Volume Up	269
Zone 7 Power On Volume Down	270
Zone 7 Balance Left	271
Zone 7 Balance Right	272
Zone 7 Max Volume Up	273
Zone 7 Max Volume Down	274
Zone 7 Loudness Toggle	275
Zone 7 Power On Volume Toggle	276
Zone 7 Mono/Stereo Toggle	277
Zone 7 Source 1 Select	255
Zone 7 Source 2 Select	256
Zone 7 Source 3 Select	257
Zone 7 Source 4 Select	258
Zone 7 Source 5 Select	259
Zone 7 Source 6 Select	260
Zone 7 Source 7 Select	261
Zone 7 Source 8 Select	262
Zone 7 Volume Level	61
Zone 7 Bass Level	62
Zone 7 Treble Level	63
Zone 7 Gain Level	64
Zone 7 Power On Volume Level	65
Zone 7 Balance Level	66
Zone 7 Max Volume Level	67
Zone 7 Zone Name	254

Function	Channel/Level
Zone 8 Power Toggle	290
Zone 8 Power On	318
Zone 8 Power Off	319
Zone 8 Mute Toggle	291
Zone 8 Mute On	320
Zone 8 Mute Off	321
Zone 8 Volume Up	292
Zone 8 Volume Down	293
Zone 8 Bass Up	303
Zone 8 Bass Down	304
Zone 8 Treble Up	305
Zone 8 Treble Down	306
Zone 8 Gain Up	307
Zone 8 Gain Down	308
Zone 8 Power On Volume Up	309
Zone 8 Power On Volume Down	310
Zone 8 Balance Left	311
Zone 8 Balance Right	312
Zone 8 Max Volume Up	313
Zone 8 Max Volume Down	314
Zone 8 Loudness Toggle	315
Zone 8 Power On Volume Toggle	316
Zone 8 Mono/Stereo Toggle	317
Zone 8 Source 1 Select	295
Zone 8 Source 2 Select	296
Zone 8 Source 3 Select	297
Zone 8 Source 4 Select	298
Zone 8 Source 5 Select	299
Zone 8 Source 6 Select	300
Zone 8 Source 7 Select	301
Zone 8 Source 8 Select	302
Zone 8 Volume Level	71
Zone 8 Bass Level	72
Zone 8 Treble Level	73
Zone 8 Gain Level	74
Zone 8 Power On Volume Level	75
Zone 8 Balance Level	76
Zone 8 Max Volume Level	77
Zone 8 Zone Name	294

Function	Channel/Level
Zone 9 Power Toggle	330
Zone 9 Power On	358
Zone 9 Power Off	359
Zone 9 Mute Toggle	331
Zone 9 Mute On	360
Zone 9 Mute Off	361
Zone 9 Volume Up	332
Zone 9 Volume Down	333
Zone 9 Bass Up	343
Zone 9 Bass Down	344
Zone 9 Treble Up	345
Zone 9 Treble Down	346
Zone 9 Gain Up	347
Zone 9 Gain Down	348
Zone 9 Power On Volume Up	349
Zone 9 Power On Volume Down	350
Zone 9 Balance Left	351
Zone 9 Balance Right	352
Zone 9 Max Volume Up	353
Zone 9 Max Volume Down	354
Zone 9 Loudness Toggle	355
Zone 9 Power On Volume Toggle	356
Zone 9 Mono/Stereo Toggle	357
Zone 9 Source 1 Select	335
Zone 9 Source 2 Select	336
Zone 9 Source 3 Select	337
Zone 9 Source 4 Select	338
Zone 9 Source 5 Select	339
Zone 9 Source 6 Select	340
Zone 9 Source 7 Select	341
Zone 9 Source 8 Select	342
Zone 9 Volume Level	81
Zone 9 Bass Level	82
Zone 9 Treble Level	83
Zone 9 Gain Level	84
Zone 9 Power On Volume Level	85
Zone 9 Balance Level	86
Zone 9 Max Volume Level	87
Zone 9 Zone Name	334

Function	Channel/Level
Zone 10 Power Toggle	370
Zone 10 Power On	398
Zone 10 Power Off	399
Zone 10 Mute Toggle	371
Zone 10 Mute On	400
Zone 10 Mute Off	401
Zone 10 Volume Up	372
Zone 10 Volume Down	373
Zone 10 Bass Up	383
Zone 10 Bass Down	384
Zone 10 Treble Up	385
Zone 10 Treble Down	386
Zone 10 Gain Up	387
Zone 10 Gain Down	388
Zone 10 Power On Volume Up	389
Zone 10 Power On Volume Down	390
Zone 10 Balance Left	391
Zone 10 Balance Right	392
Zone 10 Max Volume Up	393
Zone 10 Max Volume Down	394
Zone 10 Loudness Toggle	395
Zone 10 Power On Volume Toggle	396
Zone 10 Mono/Stereo Toggle	397
Zone 10 Source 1 Select	375
Zone 10 Source 2 Select	376
Zone 10 Source 3 Select	377
Zone 10 Source 4 Select	378
Zone 10 Source 5 Select	379
Zone 10 Source 6 Select	380
Zone 10 Source 7 Select	381
Zone 10 Source 8 Select	382
Zone 10 Volume Level	91
Zone 10 Bass Level	92
Zone 10 Treble Level	93
Zone 10 Gain Level	94
Zone 10 Power On Volume Level	95
Zone 10 Balance Level	96
Zone 10 Max Volume Level	97
Zone 10 Zone Name	374

Function	Channel/Level
Zone 11 Power Toggle	410
Zone 11 Power On	438
Zone 11 Power Off	439
Zone 11 Mute Toggle	411
Zone 11 Mute On	440
Zone 11 Mute Off	441
Zone 11 Volume Up	412
Zone 11 Volume Down	413
Zone 11 Bass Up	423
Zone 11 Bass Down	424
Zone 11 Treble Up	425
Zone 11 Treble Down	426
Zone 11 Gain Up	427
Zone 11 Gain Down	428
Zone 11 Power On Volume Up	429
Zone 11 Power On Volume Down	430
Zone 11 Balance Left	431
Zone 11 Balance Right	432
Zone 11 Max Volume Up	433
Zone 11 Max Volume Down	434
Zone 11 Loudness Toggle	435
Zone 11 Power On Volume Toggle	436
Zone 11 Mono/Stereo Toggle	437
Zone 11 Source 1 Select	415
Zone 11 Source 2 Select	416
Zone 11 Source 3 Select	417
Zone 11 Source 4 Select	418
Zone 11 Source 5 Select	419
Zone 11 Source 6 Select	420
Zone 11 Source 7 Select	421
Zone 11 Source 8 Select	422
Zone 11 Volume Level	101
Zone 11 Bass Level	102
Zone 11 Treble Level	103
Zone 11 Gain Level	104
Zone 11 Power On Volume Level	105
Zone 11 Balance Level	106
Zone 11 Max Volume Level	107
Zone 11 Zone Name	414

Function	Channel/Level
Zone 12 Power Toggle	450
Zone 12 Power On	478
Zone 12 Power Off	479
Zone 12 Mute Toggle	451
Zone 12 Mute On	480
Zone 12 Mute Off	481
Zone 12 Volume Up	452
Zone 12 Volume Down	453
Zone 12 Bass Up	463
Zone 12 Bass Down	464
Zone 12 Treble Up	465
Zone 12 Treble Down	466
Zone 12 Gain Up	467
Zone 12 Gain Down	468
Zone 12 Power On Volume Up	469
Zone 12 Power On Volume Down	470
Zone 12 Balance Left	471
Zone 12 Balance Right	472
Zone 12 Max Volume Up	473
Zone 12 Max Volume Down	474
Zone 12 Loudness Toggle	475
Zone 12 Power On Volume Toggle	476
Zone 12 Mono/Stereo Toggle	477
Zone 12 Source 1 Select	455
Zone 12 Source 2 Select	456
Zone 12 Source 3 Select	457
Zone 12 Source 4 Select	458
Zone 12 Source 5 Select	459
Zone 12 Source 6 Select	460
Zone 12 Source 7 Select	461
Zone 12 Source 8 Select	462
Zone 12 Volume Level	111
Zone 12 Bass Level	112
Zone 12 Treble Level	113
Zone 12 Gain Level	114
Zone 12 Power On Volume Level	115
Zone 12 Balance Level	116
Zone 12 Max Volume Level	117
Zone 12 Zone Name	454

Function	Channel/Level
Zone 13 Power Toggle	490
Zone 13 Power On	518
Zone 13 Power Off	519
Zone 13 Mute Toggle	491
Zone 13 Mute On	520
Zone 13 Mute Off	521
Zone 13 Volume Up	492
Zone 13 Volume Down	493
Zone 13 Bass Up	503
Zone 13 Bass Down	504
Zone 13 Treble Up	505
Zone 13 Treble Down	506
Zone 13 Gain Up	507
Zone 13 Gain Down	508
Zone 13 Power On Volume Up	509
Zone 13 Power On Volume Down	510
Zone 13 Balance Left	511
Zone 13 Balance Right	512
Zone 13 Max Volume Up	513
Zone 13 Max Volume Down	514
Zone 13 Loudness Toggle	515
Zone 13 Power On Volume Toggle	516
Zone 13 Mono/Stereo Toggle	517
Zone 13 Source 1 Select	495
Zone 13 Source 2 Select	496
Zone 13 Source 3 Select	497
Zone 13 Source 4 Select	498
Zone 13 Source 5 Select	499
Zone 13 Source 6 Select	500
Zone 13 Source 7 Select	501
Zone 13 Source 8 Select	502
Zone 13 Volume Level	121
Zone 13 Bass Level	122
Zone 13 Treble Level	123
Zone 13 Gain Level	124
Zone 13 Power On Volume Level	125
Zone 13 Balance Level	126
Zone 13 Max Volume Level	127
Zone 13 Zone Name	494

Function	Channel/Level
Zone 14 Power Toggle	530
Zone 14 Power On	558
Zone 14 Power Off	559
Zone 14 Mute Toggle	531
Zone 14 Mute On	560
Zone 14 Mute Off	561
Zone 14 Volume Up	532
Zone 14 Volume Down	533
Zone 14 Bass Up	543
Zone 14 Bass Down	544
Zone 14 Treble Up	545
Zone 14 Treble Down	546
Zone 14 Gain Up	547
Zone 14 Gain Down	548
Zone 14 Power On Volume Up	549
Zone 14 Power On Volume Down	550
Zone 14 Balance Left	551
Zone 14 Balance Right	552
Zone 14 Max Volume Up	553
Zone 14 Max Volume Down	554
Zone 14 Loudness Toggle	555
Zone 14 Power On Volume Toggle	556
Zone 14 Mono/Stereo Toggle	557
Zone 14 Source 1 Select	535
Zone 14 Source 2 Select	536
Zone 14 Source 3 Select	537
Zone 14 Source 4 Select	538
Zone 14 Source 5 Select	539
Zone 14 Source 6 Select	540
Zone 14 Source 7 Select	541
Zone 14 Source 8 Select	542
Zone 14 Volume Level	131
Zone 14 Bass Level	132
Zone 14 Treble Level	133
Zone 14 Gain Level	134
Zone 14 Power On Volume Level	135
Zone 14 Balance Level	136
Zone 14 Max Volume Level	137
Zone 14 Zone Name	534

Function	Channel/Level
Zone 15 Power Toggle	570
Zone 15 Power On	598
Zone 15 Power Off	599
Zone 15 Mute Toggle	571
Zone 15 Mute On	600
Zone 15 Mute Off	601
Zone 15 Volume Up	572
Zone 15 Volume Down	573
Zone 15 Bass Up	583
Zone 15 Bass Down	584
Zone 15 Treble Up	585
Zone 15 Treble Down	586
Zone 15 Gain Up	587
Zone 15 Gain Down	588
Zone 15 Power On Volume Up	589
Zone 15 Power On Volume Down	590
Zone 15 Balance Left	591
Zone 15 Balance Right	592
Zone 15 Max Volume Up	593
Zone 15 Max Volume Down	594
Zone 15 Loudness Toggle	595
Zone 15 Power On Volume Toggle	596
Zone 15 Mono/Stereo Toggle	597
Zone 15 Source 1 Select	575
Zone 15 Source 2 Select	576
Zone 15 Source 3 Select	577
Zone 15 Source 4 Select	578
Zone 15 Source 5 Select	579
Zone 15 Source 6 Select	580
Zone 15 Source 7 Select	581
Zone 15 Source 8 Select	582
Zone 15 Volume Level	141
Zone 15 Bass Level	142
Zone 15 Treble Level	143
Zone 15 Gain Level	144
Zone 15 Power On Volume Level	145
Zone 15 Balance Level	146
Zone 15 Max Volume Level	147
Zone 15 Zone Name	574

Function	Channel/Level
Zone 16 Power Toggle	610
Zone 16 Power On	638
Zone 16 Power Off	639
Zone 16 Mute Toggle	611
Zone 16 Mute On	640
Zone 16 Mute Off	641
Zone 16 Volume Up	612
Zone 16 Volume Down	613
Zone 16 Bass Up	623
Zone 16 Bass Down	624
Zone 16 Treble Up	625
Zone 16 Treble Down	626
Zone 16 Gain Up	627
Zone 16 Gain Down	628
Zone 16 Power On Volume Up	629
Zone 16 Power On Volume Down	630
Zone 16 Balance Left	631
Zone 16 Balance Right	632
Zone 16 Max Volume Up	633
Zone 16 Max Volume Down	634
Zone 16 Loudness Toggle	635
Zone 16 Power On Volume Toggle	636
Zone 16 Mono/Stereo Toggle	637
Zone 16 Source 1 Select	615
Zone 16 Source 2 Select	616
Zone 16 Source 3 Select	617
Zone 16 Source 4 Select	618
Zone 16 Source 5 Select	619
Zone 16 Source 6 Select	620
Zone 16 Source 7 Select	621
Zone 16 Source 8 Select	622
Zone 16 Volume Level	151
Zone 16 Bass Level	152
Zone 16 Treble Level	153
Zone 16 Gain Level	154
Zone 16 Power On Volume Level	155
Zone 16 Balance Level	156
Zone 16 Max Volume Level	157
Zone 16 Zone Name	614

Function	Channel/Level
Zone 17 Power Toggle	650
Zone 17 Power On	678
Zone 17 Power Off	679
Zone 17 Mute Toggle	651
Zone 17 Mute On	680
Zone 17 Mute Off	681
Zone 17 Volume Up	652
Zone 17 Volume Down	653
Zone 17 Bass Up	663
Zone 17 Bass Down	664
Zone 17 Treble Up	665
Zone 17 Treble Down	666
Zone 17 Gain Up	667
Zone 17 Gain Down	668
Zone 17 Power On Volume Up	669
Zone 17 Power On Volume Down	670
Zone 17 Balance Left	671
Zone 17 Balance Right	672
Zone 17 Max Volume Up	673
Zone 17 Max Volume Down	674
Zone 17 Loudness Toggle	675
Zone 17 Power On Volume Toggle	676
Zone 17 Mono/Stereo Toggle	677
Zone 17 Source 1 Select	655
Zone 17 Source 2 Select	656
Zone 17 Source 3 Select	657
Zone 17 Source 4 Select	658
Zone 17 Source 5 Select	659
Zone 17 Source 6 Select	660
Zone 17 Source 7 Select	661
Zone 17 Source 8 Select	662
Zone 17 Volume Level	161
Zone 17 Bass Level	162
Zone 17 Treble Level	163
Zone 17 Gain Level	164
Zone 17 Power On Volume Level	165
Zone 17 Balance Level	166
Zone 17 Max Volume Level	167
Zone 17 Zone Name	654

Function	Channel/Level
Zone 18 Power Toggle	690
Zone 18 Power On	718
Zone 18 Power Off	719
Zone 18 Mute Toggle	691
Zone 18 Mute On	720
Zone 18 Mute Off	721
Zone 18 Volume Up	692
Zone 18 Volume Down	693
Zone 18 Bass Up	703
Zone 18 Bass Down	704
Zone 18 Treble Up	705
Zone 18 Treble Down	706
Zone 18 Gain Up	707
Zone 18 Gain Down	708
Zone 18 Power On Volume Up	709
Zone 18 Power On Volume Down	710
Zone 18 Balance Left	711
Zone 18 Balance Right	712
Zone 18 Max Volume Up	713
Zone 18 Max Volume Down	714
Zone 18 Loudness Toggle	715
Zone 18 Power On Volume Toggle	716
Zone 18 Mono/Stereo Toggle	717
Zone 18 Source 1 Select	695
Zone 18 Source 2 Select	696
Zone 18 Source 3 Select	697
Zone 18 Source 4 Select	698
Zone 18 Source 5 Select	699
Zone 18 Source 6 Select	700
Zone 18 Source 7 Select	701
Zone 18 Source 8 Select	702
Zone 18 Volume Level	171
Zone 18 Bass Level	172
Zone 18 Treble Level	173
Zone 18 Gain Level	174
Zone 18 Power On Volume Level	175
Zone 18 Balance Level	176
Zone 18 Max Volume Level	177
Zone 18 Zone Name	694

Function	Channel/Level
Zone 19 Power Toggle	730
Zone 19 Power On	758
Zone 19 Power Off	759
Zone 19 Mute Toggle	731
Zone 19 Mute On	760
Zone 19 Mute Off	761
Zone 19 Volume Up	732
Zone 19 Volume Down	733
Zone 19 Bass Up	743
Zone 19 Bass Down	744
Zone 19 Treble Up	745
Zone 19 Treble Down	746
Zone 19 Gain Up	747
Zone 19 Gain Down	748
Zone 19 Power On Volume Up	749
Zone 19 Power On Volume Down	750
Zone 19 Balance Left	751
Zone 19 Balance Right	752
Zone 19 Max Volume Up	753
Zone 19 Max Volume Down	754
Zone 19 Loudness Toggle	755
Zone 19 Power On Volume Toggle	756
Zone 19 Mono/Stereo Toggle	757
Zone 19 Source 1 Select	735
Zone 19 Source 2 Select	736
Zone 19 Source 3 Select	737
Zone 19 Source 4 Select	738
Zone 19 Source 5 Select	739
Zone 19 Source 6 Select	740
Zone 19 Source 7 Select	741
Zone 19 Source 8 Select	742
Zone 19 Volume Level	181
Zone 19 Bass Level	182
Zone 19 Treble Level	183
Zone 19 Gain Level	184
Zone 19 Power On Volume Level	185
Zone 19 Balance Level	186
Zone 19 Max Volume Level	187
Zone 19 Zone Name	734

Function	Channel/Level
Zone 20 Power Toggle	770
Zone 20 Power On	798
Zone 20 Power Off	799
Zone 20 Mute Toggle	771
Zone 20 Mute On	800
Zone 20 Mute Off	801
Zone 20 Volume Up	772
Zone 20 Volume Down	773
Zone 20 Bass Up	783
Zone 20 Bass Down	784
Zone 20 Treble Up	785
Zone 20 Treble Down	786
Zone 20 Gain Up	787
Zone 20 Gain Down	788
Zone 20 Power On Volume Up	789
Zone 20 Power On Volume Down	790
Zone 20 Balance Left	791
Zone 20 Balance Right	792
Zone 20 Max Volume Up	793
Zone 20 Max Volume Down	794
Zone 20 Loudness Toggle	795
Zone 20 Power On Volume Toggle	796
Zone 20 Mono/Stereo Toggle	797
Zone 20 Source 1 Select	775
Zone 20 Source 2 Select	776
Zone 20 Source 3 Select	777
Zone 20 Source 4 Select	778
Zone 20 Source 5 Select	779
Zone 20 Source 6 Select	780
Zone 20 Source 7 Select	781
Zone 20 Source 8 Select	782
Zone 20 Volume Level	191
Zone 20 Bass Level	192
Zone 20 Treble Level	193
Zone 20 Gain Level	194
Zone 20 Power On Volume Level	195
Zone 20 Balance Level	196
Zone 20 Max Volume Level	197
Zone 20 Zone Name	774

Function	Channel/Level
Zone 21 Power Toggle	810
Zone 21 Power On	838
Zone 21 Power Off	839
Zone 21 Mute Toggle	811
Zone 21 Mute On	840
Zone 21 Mute Off	841
Zone 21 Volume Up	812
Zone 21 Volume Down	813
Zone 21 Bass Up	823
Zone 21 Bass Down	824
Zone 21 Treble Up	825
Zone 21 Treble Down	826
Zone 21 Gain Up	827
Zone 21 Gain Down	828
Zone 21 Power On Volume Up	829
Zone 21 Power On Volume Down	830
Zone 21 Balance Left	831
Zone 21 Balance Right	832
Zone 21 Max Volume Up	833
Zone 21 Max Volume Down	834
Zone 21 Loudness Toggle	835
Zone 21 Power On Volume Toggle	836
Zone 21 Mono/Stereo Toggle	837
Zone 21 Source 1 Select	815
Zone 21 Source 2 Select	816
Zone 21 Source 3 Select	817
Zone 21 Source 4 Select	818
Zone 21 Source 5 Select	819
Zone 21 Source 6 Select	820
Zone 21 Source 7 Select	821
Zone 21 Source 8 Select	822
Zone 21 Volume Level	201
Zone 21 Bass Level	202
Zone 21 Treble Level	203
Zone 21 Gain Level	204
Zone 21 Power On Volume Level	205
Zone 21 Balance Level	206
Zone 21 Max Volume Level	207
Zone 21 Zone Name	814

Function	Channel/Level
Zone 22 Power Toggle	850
Zone 22 Power On	878
Zone 22 Power Off	879
Zone 22 Mute Toggle	851
Zone 22 Mute On	880
Zone 22 Mute Off	881
Zone 22 Volume Up	852
Zone 22 Volume Down	853
Zone 22 Bass Up	863
Zone 22 Bass Down	864
Zone 22 Treble Up	865
Zone 22 Treble Down	866
Zone 22 Gain Up	867
Zone 22 Gain Down	868
Zone 22 Power On Volume Up	869
Zone 22 Power On Volume Down	870
Zone 22 Balance Left	871
Zone 22 Balance Right	872
Zone 22 Max Volume Up	873
Zone 22 Max Volume Down	874
Zone 22 Loudness Toggle	875
Zone 22 Power On Volume Toggle	876
Zone 22 Mono/Stereo Toggle	877
Zone 22 Source 1 Select	855
Zone 22 Source 2 Select	856
Zone 22 Source 3 Select	857
Zone 22 Source 4 Select	858
Zone 22 Source 5 Select	859
Zone 22 Source 6 Select	860
Zone 22 Source 7 Select	861
Zone 22 Source 8 Select	862
Zone 22 Volume Level	211
Zone 22 Bass Level	212
Zone 22 Treble Level	213
Zone 22 Gain Level	214
Zone 22 Power On Volume Level	215
Zone 22 Balance Level	216
Zone 22 Max Volume Level	217
Zone 22 Zone Name	854

Function	Channel/Level
Zone 23 Power Toggle	890
Zone 23 Power On	918
Zone 23 Power Off	919
Zone 23 Mute Toggle	891
Zone 23 Mute On	920
Zone 23 Mute Off	921
Zone 23 Volume Up	892
Zone 23 Volume Down	893
Zone 23 Bass Up	903
Zone 23 Bass Down	904
Zone 23 Treble Up	905
Zone 23 Treble Down	906
Zone 23 Gain Up	907
Zone 23 Gain Down	908
Zone 23 Power On Volume Up	909
Zone 23 Power On Volume Down	910
Zone 23 Balance Left	911
Zone 23 Balance Right	912
Zone 23 Max Volume Up	913
Zone 23 Max Volume Down	914
Zone 23 Loudness Toggle	915
Zone 23 Power On Volume Toggle	916
Zone 23 Mono/Stereo Toggle	917
Zone 23 Source 1 Select	895
Zone 23 Source 2 Select	896
Zone 23 Source 3 Select	897
Zone 23 Source 4 Select	898
Zone 23 Source 5 Select	899
Zone 23 Source 6 Select	900
Zone 23 Source 7 Select	901
Zone 23 Source 8 Select	902
Zone 23 Volume Level	221
Zone 23 Bass Level	222
Zone 23 Treble Level	223
Zone 23 Gain Level	224
Zone 23 Power On Volume Level	225
Zone 23 Balance Level	226
Zone 23 Max Volume Level	227
Zone 23 Zone Name	894

Function	Channel/Level
Zone 24 Power Toggle	930
Zone 24 Power On	958
Zone 24 Power Off	959
Zone 24 Mute Toggle	931
Zone 24 Mute On	960
Zone 24 Mute Off	961
Zone 24 Volume Up	932
Zone 24 Volume Down	933
Zone 24 Bass Up	943
Zone 24 Bass Down	944
Zone 24 Treble Up	945
Zone 24 Treble Down	946
Zone 24 Gain Up	947
Zone 24 Gain Down	948
Zone 24 Power On Volume Up	949
Zone 24 Power On Volume Down	950
Zone 24 Balance Left	951
Zone 24 Balance Right	952
Zone 24 Max Volume Up	953
Zone 24 Max Volume Down	954
Zone 24 Loudness Toggle	955
Zone 24 Power On Volume Toggle	956
Zone 24 Mono/Stereo Toggle	957
Zone 24 Source 1 Select	935
Zone 24 Source 2 Select	936
Zone 24 Source 3 Select	937
Zone 24 Source 4 Select	938
Zone 24 Source 5 Select	939
Zone 24 Source 6 Select	940
Zone 24 Source 7 Select	941
Zone 24 Source 8 Select	942
Zone 24 Volume Level	231
Zone 24 Bass Level	232
Zone 24 Treble Level	233
Zone 24 Gain Level	234
Zone 24 Power On Volume Level	235
Zone 24 Balance Level	236
Zone 24 Max Volume Level	237
Zone 24 Zone Name	934

Function	Channel/Level
Zone 25 Power Toggle	970
Zone 25 Power On	998
Zone 25 Power Off	999
Zone 25 Mute Toggle	971
Zone 25 Mute On	1000
Zone 25 Mute Off	1001
Zone 25 Volume Up	972
Zone 25 Volume Down	973
Zone 25 Bass Up	983
Zone 25 Bass Down	984
Zone 25 Treble Up	985
Zone 25 Treble Down	986
Zone 25 Gain Up	987
Zone 25 Gain Down	988
Zone 25 Power On Volume Up	989
Zone 25 Power On Volume Down	990
Zone 25 Balance Left	991
Zone 25 Balance Right	992
Zone 25 Max Volume Up	993
Zone 25 Max Volume Down	994
Zone 25 Loudness Toggle	995
Zone 25 Power On Volume Toggle	996
Zone 25 Mono/Stereo Toggle	997
Zone 25 Source 1 Select	975
Zone 25 Source 2 Select	976
Zone 25 Source 3 Select	977
Zone 25 Source 4 Select	978
Zone 25 Source 5 Select	979
Zone 25 Source 6 Select	980
Zone 25 Source 7 Select	981
Zone 25 Source 8 Select	982
Zone 25 Volume Level	241
Zone 25 Bass Level	242
Zone 25 Treble Level	243
Zone 25 Gain Level	244
Zone 25 Power On Volume Level	245
Zone 25 Balance Level	246
Zone 25 Max Volume Level	247
Zone 25 Zone Name	974

Function	Channel/Level
Zone 26 Power Toggle	1010
Zone 26 Power On	1038
Zone 26 Power Off	1039
Zone 26 Mute Toggle	1011
Zone 26 Mute On	1040
Zone 26 Mute Off	1041
Zone 26 Volume Up	1012
Zone 26 Volume Down	1013
Zone 26 Bass Up	1023
Zone 26 Bass Down	1024
Zone 26 Treble Up	1025
Zone 26 Treble Down	1026
Zone 26 Gain Up	1027
Zone 26 Gain Down	1028
Zone 26 Power On Volume Up	1029
Zone 26 Power On Volume Down	1030
Zone 26 Balance Left	1031
Zone 26 Balance Right	1032
Zone 26 Max Volume Up	1033
Zone 26 Max Volume Down	1034
Zone 26 Loudness Toggle	1035
Zone 26 Power On Volume Toggle	1036
Zone 26 Mono/Stereo Toggle	1037
Zone 26 Source 1 Select	1015
Zone 26 Source 2 Select	1016
Zone 26 Source 3 Select	1017
Zone 26 Source 4 Select	1018
Zone 26 Source 5 Select	1019
Zone 26 Source 6 Select	1020
Zone 26 Source 7 Select	1021
Zone 26 Source 8 Select	1022
Zone 26 Volume Level	251
Zone 26 Bass Level	252
Zone 26 Treble Level	253
Zone 26 Gain Level	254
Zone 26 Power On Volume Level	255
Zone 26 Balance Level	256
Zone 26 Max Volume Level	257
Zone 26 Zone Name	1014

Function	Channel/Level
Zone 27 Power Toggle	1050
Zone 27 Power On	1078
Zone 27 Power Off	1079
Zone 27 Mute Toggle	1051
Zone 27 Mute On	1080
Zone 27 Mute Off	1081
Zone 27 Volume Up	1052
Zone 27 Volume Down	1053
Zone 27 Bass Up	1063
Zone 27 Bass Down	1064
Zone 27 Treble Up	1065
Zone 27 Treble Down	1066
Zone 27 Gain Up	1067
Zone 27 Gain Down	1068
Zone 27 Power On Volume Up	1069
Zone 27 Power On Volume Down	1070
Zone 27 Balance Left	1071
Zone 27 Balance Right	1072
Zone 27 Max Volume Up	1073
Zone 27 Max Volume Down	1074
Zone 27 Loudness Toggle	1075
Zone 27 Power On Volume Toggle	1076
Zone 27 Mono/Stereo Toggle	1077
Zone 27 Source 1 Select	1055
Zone 27 Source 2 Select	1056
Zone 27 Source 3 Select	1057
Zone 27 Source 4 Select	1058
Zone 27 Source 5 Select	1059
Zone 27 Source 6 Select	1060
Zone 27 Source 7 Select	1061
Zone 27 Source 8 Select	1062
Zone 27 Volume Level	261
Zone 27 Bass Level	262
Zone 27 Treble Level	263
Zone 27 Gain Level	264
Zone 27 Power On Volume Level	265
Zone 27 Balance Level	266
Zone 27 Max Volume Level	267
Zone 27 Zone Name	1054

Function	Channel/Level
Zone 28 Power Toggle	1090
Zone 28 Power On	1118
Zone 28 Power Off	1119
Zone 28 Mute Toggle	1091
Zone 28 Mute On	1120
Zone 28 Mute Off	1121
Zone 28 Volume Up	1092
Zone 28 Volume Down	1093
Zone 28 Bass Up	1103
Zone 28 Bass Down	1104
Zone 28 Treble Up	1105
Zone 28 Treble Down	1106
Zone 28 Gain Up	1107
Zone 28 Gain Down	1108
Zone 28 Power On Volume Up	1109
Zone 28 Power On Volume Down	1110
Zone 28 Balance Left	1111
Zone 28 Balance Right	1112
Zone 28 Max Volume Up	1113
Zone 28 Max Volume Down	1114
Zone 28 Loudness Toggle	1115
Zone 28 Power On Volume Toggle	1116
Zone 28 Mono/Stereo Toggle	1117
Zone 28 Source 1 Select	1095
Zone 28 Source 2 Select	1096
Zone 28 Source 3 Select	1097
Zone 28 Source 4 Select	1098
Zone 28 Source 5 Select	1099
Zone 28 Source 6 Select	1100
Zone 28 Source 7 Select	1101
Zone 28 Source 8 Select	1102
Zone 28 Volume Level	271
Zone 28 Bass Level	272
Zone 28 Treble Level	273
Zone 28 Gain Level	274
Zone 28 Power On Volume Level	275
Zone 28 Balance Level	276
Zone 28 Max Volume Level	277
Zone 28 Zone Name	1094

Function	Channel/Level
Zone 29 Power Toggle	1130
Zone 29 Power On	1158
Zone 29 Power Off	1159
Zone 29 Mute Toggle	1131
Zone 29 Mute On	1160
Zone 29 Mute Off	1161
Zone 29 Volume Up	1132
Zone 29 Volume Down	1133
Zone 29 Bass Up	1143
Zone 29 Bass Down	1144
Zone 29 Treble Up	1145
Zone 29 Treble Down	1146
Zone 29 Gain Up	1147
Zone 29 Gain Down	1148
Zone 29 Power On Volume Up	1149
Zone 29 Power On Volume Down	1150
Zone 29 Balance Left	1151
Zone 29 Balance Right	1152
Zone 29 Max Volume Up	1153
Zone 29 Max Volume Down	1154
Zone 29 Loudness Toggle	1155
Zone 29 Power On Volume Toggle	1156
Zone 29 Mono/Stereo Toggle	1157
Zone 29 Source 1 Select	1135
Zone 29 Source 2 Select	1136
Zone 29 Source 3 Select	1137
Zone 29 Source 4 Select	1138
Zone 29 Source 5 Select	1139
Zone 29 Source 6 Select	1140
Zone 29 Source 7 Select	1141
Zone 29 Source 8 Select	1142
Zone 29 Volume Level	281
Zone 29 Bass Level	282
Zone 29 Treble Level	283
Zone 29 Gain Level	284
Zone 29 Power On Volume Level	285
Zone 29 Balance Level	286
Zone 29 Max Volume Level	287
Zone 29 Zone Name	1134

Function	Channel/Level
Zone 30 Power Toggle	1170
Zone 30 Power On	1198
Zone 30 Power Off	1199
Zone 30 Mute Toggle	1171
Zone 30 Mute On	1200
Zone 30 Mute Off	1201
Zone 30 Volume Up	1172
Zone 30 Volume Down	1173
Zone 30 Bass Up	1183
Zone 30 Bass Down	1184
Zone 30 Treble Up	1185
Zone 30 Treble Down	1186
Zone 30 Gain Up	1187
Zone 30 Gain Down	1188
Zone 30 Power On Volume Up	1189
Zone 30 Power On Volume Down	1190
Zone 30 Balance Left	1191
Zone 30 Balance Right	1192
Zone 30 Max Volume Up	1193
Zone 30 Max Volume Down	1194
Zone 30 Loudness Toggle	1195
Zone 30 Power On Volume Toggle	1196
Zone 30 Mono/Stereo Toggle	1197
Zone 30 Source 1 Select	1175
Zone 30 Source 2 Select	1176
Zone 30 Source 3 Select	1177
Zone 30 Source 4 Select	1178
Zone 30 Source 5 Select	1179
Zone 30 Source 6 Select	1180
Zone 30 Source 7 Select	1181
Zone 30 Source 8 Select	1182
Zone 30 Volume Level	291
Zone 30 Bass Level	292
Zone 30 Treble Level	293
Zone 30 Gain Level	294
Zone 30 Power On Volume Level	295
Zone 30 Balance Level	296
Zone 30 Max Volume Level	297
Zone 30 Zone Name	1174

Function	Channel/Level
Zone 31 Power Toggle	1210
Zone 31 Power On	1238
Zone 31 Power Off	1239
Zone 31 Mute Toggle	1211
Zone 31 Mute On	1240
Zone 31 Mute Off	1241
Zone 31 Volume Up	1212
Zone 31 Volume Down	1213
Zone 31 Bass Up	1223
Zone 31 Bass Down	1224
Zone 31 Treble Up	1225
Zone 31 Treble Down	1226
Zone 31 Gain Up	1227
Zone 31 Gain Down	1228
Zone 31 Power On Volume Up	1229
Zone 31 Power On Volume Down	1230
Zone 31 Balance Left	1231
Zone 31 Balance Right	1232
Zone 31 Max Volume Up	1233
Zone 31 Max Volume Down	1234
Zone 31 Loudness Toggle	1235
Zone 31 Power On Volume Toggle	1236
Zone 31 Mono/Stereo Toggle	1237
Zone 31 Source 1 Select	1215
Zone 31 Source 2 Select	1216
Zone 31 Source 3 Select	1217
Zone 31 Source 4 Select	1218
Zone 31 Source 5 Select	1219
Zone 31 Source 6 Select	1220
Zone 31 Source 7 Select	1221
Zone 31 Source 8 Select	1222
Zone 31 Volume Level	301
Zone 31 Bass Level	302
Zone 31 Treble Level	303
Zone 31 Gain Level	304
Zone 31 Power On Volume Level	305
Zone 31 Balance Level	306
Zone 31 Max Volume Level	307
Zone 31 Zone Name	1214

Function	Channel/Level
Zone 32 Power Toggle	1250
Zone 32 Power On	1278
Zone 32 Power Off	1279
Zone 32 Mute Toggle	1251
Zone 32 Mute On	1280
Zone 32 Mute Off	1281
Zone 32 Volume Up	1252
Zone 32 Volume Down	1253
Zone 32 Bass Up	1263
Zone 32 Bass Down	1264
Zone 32 Treble Up	1265
Zone 32 Treble Down	1266
Zone 32 Gain Up	1267
Zone 32 Gain Down	1268
Zone 32 Power On Volume Up	1269
Zone 32 Power On Volume Down	1270
Zone 32 Balance Left	1271
Zone 32 Balance Right	1272
Zone 32 Max Volume Up	1273
Zone 32 Max Volume Down	1274
Zone 32 Loudness Toggle	1275
Zone 32 Power On Volume Toggle	1276
Zone 32 Mono/Stereo Toggle	1277
Zone 32 Source 1 Select	1255
Zone 32 Source 2 Select	1256
Zone 32 Source 3 Select	1257
Zone 32 Source 4 Select	1258
Zone 32 Source 5 Select	1259
Zone 32 Source 6 Select	1260
Zone 32 Source 7 Select	1261
Zone 32 Source 8 Select	1262
Zone 32 Volume Level	311
Zone 32 Bass Level	312
Zone 32 Treble Level	313
Zone 32 Gain Level	314
Zone 32 Power On Volume Level	315
Zone 32 Balance Level	316
Zone 32 Max Volume Level	317
Zone 32 Zone Name	1254

Function	Channel/Level
Zone 33 Power Toggle	1290
Zone 33 Power On	1318
Zone 33 Power Off	1319
Zone 33 Mute Toggle	1291
Zone 33 Mute On	1320
Zone 33 Mute Off	1321
Zone 33 Volume Up	1292
Zone 33 Volume Down	1293
Zone 33 Bass Up	1303
Zone 33 Bass Down	1304
Zone 33 Treble Up	1305
Zone 33 Treble Down	1306
Zone 33 Gain Up	1307
Zone 33 Gain Down	1308
Zone 33 Power On Volume Up	1309
Zone 33 Power On Volume Down	1310
Zone 33 Balance Left	1311
Zone 33 Balance Right	1312
Zone 33 Max Volume Up	1313
Zone 33 Max Volume Down	1314
Zone 33 Loudness Toggle	1315
Zone 33 Power On Volume Toggle	1316
Zone 33 Mono/Stereo Toggle	1317
Zone 33 Source 1 Select	1295
Zone 33 Source 2 Select	1296
Zone 33 Source 3 Select	1297
Zone 33 Source 4 Select	1298
Zone 33 Source 5 Select	1299
Zone 33 Source 6 Select	1300
Zone 33 Source 7 Select	1301
Zone 33 Source 8 Select	1302
Zone 33 Volume Level	321
Zone 33 Bass Level	322
Zone 33 Treble Level	323
Zone 33 Gain Level	324
Zone 33 Power On Volume Level	325
Zone 33 Balance Level	326
Zone 33 Max Volume Level	327
Zone 33 Zone Name	1294

Function	Channel/Level
Zone 34 Power Toggle	1330
Zone 34 Power On	1358
Zone 34 Power Off	1359
Zone 34 Mute Toggle	1331
Zone 34 Mute On	1360
Zone 34 Mute Off	1361
Zone 34 Volume Up	1332
Zone 34 Volume Down	1333
Zone 34 Bass Up	1343
Zone 34 Bass Down	1344
Zone 34 Treble Up	1345
Zone 34 Treble Down	1346
Zone 34 Gain Up	1347
Zone 34 Gain Down	1348
Zone 34 Power On Volume Up	1349
Zone 34 Power On Volume Down	1350
Zone 34 Balance Left	1351
Zone 34 Balance Right	1352
Zone 34 Max Volume Up	1353
Zone 34 Max Volume Down	1354
Zone 34 Loudness Toggle	1355
Zone 34 Power On Volume Toggle	1356
Zone 34 Mono/Stereo Toggle	1357
Zone 34 Source 1 Select	1335
Zone 34 Source 2 Select	1336
Zone 34 Source 3 Select	1337
Zone 34 Source 4 Select	1338
Zone 34 Source 5 Select	1339
Zone 34 Source 6 Select	1340
Zone 34 Source 7 Select	1341
Zone 34 Source 8 Select	1342
Zone 34 Volume Level	331
Zone 34 Bass Level	332
Zone 34 Treble Level	333
Zone 34 Gain Level	334
Zone 34 Power On Volume Level	335
Zone 34 Balance Level	336
Zone 34 Max Volume Level	337
Zone 34 Zone Name	1334

Function	Channel/Level
Zone 35 Power Toggle	1370
Zone 35 Power On	1398
Zone 35 Power Off	1399
Zone 35 Mute Toggle	1371
Zone 35 Mute On	1400
Zone 35 Mute Off	1401
Zone 35 Volume Up	1372
Zone 35 Volume Down	1373
Zone 35 Bass Up	1383
Zone 35 Bass Down	1384
Zone 35 Treble Up	1385
Zone 35 Treble Down	1386
Zone 35 Gain Up	1387
Zone 35 Gain Down	1388
Zone 35 Power On Volume Up	1389
Zone 35 Power On Volume Down	1390
Zone 35 Balance Left	1391
Zone 35 Balance Right	1392
Zone 35 Max Volume Up	1393
Zone 35 Max Volume Down	1394
Zone 35 Loudness Toggle	1395
Zone 35 Power On Volume Toggle	1396
Zone 35 Mono/Stereo Toggle	1397
Zone 35 Source 1 Select	1375
Zone 35 Source 2 Select	1376
Zone 35 Source 3 Select	1377
Zone 35 Source 4 Select	1378
Zone 35 Source 5 Select	1379
Zone 35 Source 6 Select	1380
Zone 35 Source 7 Select	1381
Zone 35 Source 8 Select	1382
Zone 35 Volume Level	341
Zone 35 Bass Level	342
Zone 35 Treble Level	343
Zone 35 Gain Level	344
Zone 35 Power On Volume Level	345
Zone 35 Balance Level	346
Zone 35 Max Volume Level	347
Zone 35 Zone Name	1374

Function	Channel/Level
Zone 36 Power Toggle	1410
Zone 36 Power On	1438
Zone 36 Power Off	1439
Zone 36 Mute Toggle	1411
Zone 36 Mute On	1440
Zone 36 Mute Off	1441
Zone 36 Volume Up	1412
Zone 36 Volume Down	1413
Zone 36 Bass Up	1423
Zone 36 Bass Down	1424
Zone 36 Treble Up	1425
Zone 36 Treble Down	1426
Zone 36 Gain Up	1427
Zone 36 Gain Down	1428
Zone 36 Power On Volume Up	1429
Zone 36 Power On Volume Down	1430
Zone 36 Balance Left	1431
Zone 36 Balance Right	1432
Zone 36 Max Volume Up	1433
Zone 36 Max Volume Down	1434
Zone 36 Loudness Toggle	1435
Zone 36 Power On Volume Toggle	1436
Zone 36 Mono/Stereo Toggle	1437
Zone 36 Source 1 Select	1415
Zone 36 Source 2 Select	1416
Zone 36 Source 3 Select	1417
Zone 36 Source 4 Select	1418
Zone 36 Source 5 Select	1419
Zone 36 Source 6 Select	1420
Zone 36 Source 7 Select	1421
Zone 36 Source 8 Select	1422
Zone 36 Volume Level	351
Zone 36 Bass Level	352
Zone 36 Treble Level	353
Zone 36 Gain Level	354
Zone 36 Power On Volume Level	355
Zone 36 Balance Level	356
Zone 36 Max Volume Level	357
Zone 36 Zone Name	1414

Function	Channel/Level
Zone 37 Power Toggle	1450
Zone 37 Power On	1478
Zone 37 Power Off	1479
Zone 37 Mute Toggle	1451
Zone 37 Mute On	1480
Zone 37 Mute Off	1481
Zone 37 Volume Up	1452
Zone 37 Volume Down	1453
Zone 37 Bass Up	1463
Zone 37 Bass Down	1464
Zone 37 Treble Up	1465
Zone 37 Treble Down	1466
Zone 37 Gain Up	1467
Zone 37 Gain Down	1468
Zone 37 Power On Volume Up	1469
Zone 37 Power On Volume Down	1470
Zone 37 Balance Left	1471
Zone 37 Balance Right	1472
Zone 37 Max Volume Up	1473
Zone 37 Max Volume Down	1474
Zone 37 Loudness Toggle	1475
Zone 37 Power On Volume Toggle	1476
Zone 37 Mono/Stereo Toggle	1477
Zone 37 Source 1 Select	1455
Zone 37 Source 2 Select	1456
Zone 37 Source 3 Select	1457
Zone 37 Source 4 Select	1458
Zone 37 Source 5 Select	1459
Zone 37 Source 6 Select	1460
Zone 37 Source 7 Select	1461
Zone 37 Source 8 Select	1462
Zone 37 Volume Level	361
Zone 37 Bass Level	362
Zone 37 Treble Level	363
Zone 37 Gain Level	364
Zone 37 Power On Volume Level	365
Zone 37 Balance Level	366
Zone 37 Max Volume Level	367
Zone 37 Zone Name	1454

Function	Channel/Level
Zone 38 Power Toggle	1490
Zone 38 Power On	1518
Zone 38 Power Off	1519
Zone 38 Mute Toggle	1491
Zone 38 Mute On	1520
Zone 38 Mute Off	1521
Zone 38 Volume Up	1492
Zone 38 Volume Down	1493
Zone 38 Bass Up	1503
Zone 38 Bass Down	1504
Zone 38 Treble Up	1505
Zone 38 Treble Down	1506
Zone 38 Gain Up	1507
Zone 38 Gain Down	1508
Zone 38 Power On Volume Up	1509
Zone 38 Power On Volume Down	1510
Zone 38 Balance Left	1511
Zone 38 Balance Right	1512
Zone 38 Max Volume Up	1513
Zone 38 Max Volume Down	1514
Zone 38 Loudness Toggle	1515
Zone 38 Power On Volume Toggle	1516
Zone 38 Mono/Stereo Toggle	1517
Zone 38 Source 1 Select	1495
Zone 38 Source 2 Select	1496
Zone 38 Source 3 Select	1497
Zone 38 Source 4 Select	1498
Zone 38 Source 5 Select	1499
Zone 38 Source 6 Select	1500
Zone 38 Source 7 Select	1501
Zone 38 Source 8 Select	1502
Zone 38 Volume Level	371
Zone 38 Bass Level	372
Zone 38 Treble Level	373
Zone 38 Gain Level	374
Zone 38 Power On Volume Level	375
Zone 38 Balance Level	376
Zone 38 Max Volume Level	377
Zone 38 Zone Name	1494

Function	Channel/Level
Zone 39 Power Toggle	1530
Zone 39 Power On	1558
Zone 39 Power Off	1559
Zone 39 Mute Toggle	1531
Zone 39 Mute On	1560
Zone 39 Mute Off	1561
Zone 39 Volume Up	1532
Zone 39 Volume Down	1533
Zone 39 Bass Up	1543
Zone 39 Bass Down	1544
Zone 39 Treble Up	1545
Zone 39 Treble Down	1546
Zone 39 Gain Up	1547
Zone 39 Gain Down	1548
Zone 39 Power On Volume Up	1549
Zone 39 Power On Volume Down	1550
Zone 39 Balance Left	1551
Zone 39 Balance Right	1552
Zone 39 Max Volume Up	1553
Zone 39 Max Volume Down	1554
Zone 39 Loudness Toggle	1555
Zone 39 Power On Volume Toggle	1556
Zone 39 Mono/Stereo Toggle	1557
Zone 39 Source 1 Select	1535
Zone 39 Source 2 Select	1536
Zone 39 Source 3 Select	1537
Zone 39 Source 4 Select	1538
Zone 39 Source 5 Select	1539
Zone 39 Source 6 Select	1540
Zone 39 Source 7 Select	1541
Zone 39 Source 8 Select	1542
Zone 39 Volume Level	381
Zone 39 Bass Level	382
Zone 39 Treble Level	383
Zone 39 Gain Level	384
Zone 39 Power On Volume Level	385
Zone 39 Balance Level	386
Zone 39 Max Volume Level	387
Zone 39 Zone Name	1534

Function	Channel/Level
Zone 40 Power Toggle	1570
Zone 40 Power On	1598
Zone 40 Power Off	1599
Zone 40 Mute Toggle	1571
Zone 40 Mute On	1600
Zone 40 Mute Off	1601
Zone 40 Volume Up	1572
Zone 40 Volume Down	1573
Zone 40 Bass Up	1583
Zone 40 Bass Down	1584
Zone 40 Treble Up	1585
Zone 40 Treble Down	1586
Zone 40 Gain Up	1587
Zone 40 Gain Down	1588
Zone 40 Power On Volume Up	1589
Zone 40 Power On Volume Down	1590
Zone 40 Balance Left	1591
Zone 40 Balance Right	1592
Zone 40 Max Volume Up	1593
Zone 40 Max Volume Down	1594
Zone 40 Loudness Toggle	1595
Zone 40 Power On Volume Toggle	1596
Zone 40 Mono/Stereo Toggle	1597
Zone 40 Source 1 Select	1575
Zone 40 Source 2 Select	1576
Zone 40 Source 3 Select	1577
Zone 40 Source 4 Select	1578
Zone 40 Source 5 Select	1579
Zone 40 Source 6 Select	1580
Zone 40 Source 7 Select	1581
Zone 40 Source 8 Select	1582
Zone 40 Volume Level	391
Zone 40 Bass Level	392
Zone 40 Treble Level	393
Zone 40 Gain Level	394
Zone 40 Power On Volume Level	395
Zone 40 Balance Level	396
Zone 40 Max Volume Level	397
Zone 40 Zone Name	1574

Function	Channel/Level
Zone 41 Power Toggle	1610
Zone 41 Power On	1638
Zone 41 Power Off	1639
Zone 41 Mute Toggle	1611
Zone 41 Mute On	1640
Zone 41 Mute Off	1641
Zone 41 Volume Up	1612
Zone 41 Volume Down	1613
Zone 41 Bass Up	1623
Zone 41 Bass Down	1624
Zone 41 Treble Up	1625
Zone 41 Treble Down	1626
Zone 41 Gain Up	1627
Zone 41 Gain Down	1628
Zone 41 Power On Volume Up	1629
Zone 41 Power On Volume Down	1630
Zone 41 Balance Left	1631
Zone 41 Balance Right	1632
Zone 41 Max Volume Up	1633
Zone 41 Max Volume Down	1634
Zone 41 Loudness Toggle	1635
Zone 41 Power On Volume Toggle	1636
Zone 41 Mono/Stereo Toggle	1637
Zone 41 Source 1 Select	1615
Zone 41 Source 2 Select	1616
Zone 41 Source 3 Select	1617
Zone 41 Source 4 Select	1618
Zone 41 Source 5 Select	1619
Zone 41 Source 6 Select	1620
Zone 41 Source 7 Select	1621
Zone 41 Source 8 Select	1622
Zone 41 Volume Level	401
Zone 41 Bass Level	402
Zone 41 Treble Level	403
Zone 41 Gain Level	404
Zone 41 Power On Volume Level	405
Zone 41 Balance Level	406
Zone 41 Max Volume Level	407
Zone 41 Zone Name	1614

Function	Channel/Level
Zone 42 Power Toggle	1650
Zone 42 Power On	1678
Zone 42 Power Off	1679
Zone 42 Mute Toggle	1651
Zone 42 Mute On	1680
Zone 42 Mute Off	1681
Zone 42 Volume Up	1652
Zone 42 Volume Down	1653
Zone 42 Bass Up	1663
Zone 42 Bass Down	1664
Zone 42 Treble Up	1665
Zone 42 Treble Down	1666
Zone 42 Gain Up	1667
Zone 42 Gain Down	1668
Zone 42 Power On Volume Up	1669
Zone 42 Power On Volume Down	1670
Zone 42 Balance Left	1671
Zone 42 Balance Right	1672
Zone 42 Max Volume Up	1673
Zone 42 Max Volume Down	1674
Zone 42 Loudness Toggle	1675
Zone 42 Power On Volume Toggle	1676
Zone 42 Mono/Stereo Toggle	1677
Zone 42 Source 1 Select	1655
Zone 42 Source 2 Select	1656
Zone 42 Source 3 Select	1657
Zone 42 Source 4 Select	1658
Zone 42 Source 5 Select	1659
Zone 42 Source 6 Select	1660
Zone 42 Source 7 Select	1661
Zone 42 Source 8 Select	1662
Zone 42 Volume Level	411
Zone 42 Bass Level	412
Zone 42 Treble Level	413
Zone 42 Gain Level	414
Zone 42 Power On Volume Level	415
Zone 42 Balance Level	416
Zone 42 Max Volume Level	417
Zone 42 Zone Name	1654

Function	Channel/Level
Zone 43 Power Toggle	1690
Zone 43 Power On	1718
Zone 43 Power Off	1719
Zone 43 Mute Toggle	1691
Zone 43 Mute On	1720
Zone 43 Mute Off	1721
Zone 43 Volume Up	1692
Zone 43 Volume Down	1693
Zone 43 Bass Up	1703
Zone 43 Bass Down	1704
Zone 43 Treble Up	1705
Zone 43 Treble Down	1706
Zone 43 Gain Up	1707
Zone 43 Gain Down	1708
Zone 43 Power On Volume Up	1709
Zone 43 Power On Volume Down	1710
Zone 43 Balance Left	1711
Zone 43 Balance Right	1712
Zone 43 Max Volume Up	1713
Zone 43 Max Volume Down	1714
Zone 43 Loudness Toggle	1715
Zone 43 Power On Volume Toggle	1716
Zone 43 Mono/Stereo Toggle	1717
Zone 43 Source 1 Select	1695
Zone 43 Source 2 Select	1696
Zone 43 Source 3 Select	1697
Zone 43 Source 4 Select	1698
Zone 43 Source 5 Select	1699
Zone 43 Source 6 Select	1700
Zone 43 Source 7 Select	1701
Zone 43 Source 8 Select	1702
Zone 43 Volume Level	421
Zone 43 Bass Level	422
Zone 43 Treble Level	423
Zone 43 Gain Level	424
Zone 43 Power On Volume Level	425
Zone 43 Balance Level	426
Zone 43 Max Volume Level	427
Zone 43 Zone Name	1694

Function	Channel/Level
Zone 44 Power Toggle	1730
Zone 44 Power On	1758
Zone 44 Power Off	1759
Zone 44 Mute Toggle	1731
Zone 44 Mute On	1760
Zone 44 Mute Off	1761
Zone 44 Volume Up	1732
Zone 44 Volume Down	1733
Zone 44 Bass Up	1743
Zone 44 Bass Down	1744
Zone 44 Treble Up	1745
Zone 44 Treble Down	1746
Zone 44 Gain Up	1747
Zone 44 Gain Down	1748
Zone 44 Power On Volume Up	1749
Zone 44 Power On Volume Down	1750
Zone 44 Balance Left	1751
Zone 44 Balance Right	1752
Zone 44 Max Volume Up	1753
Zone 44 Max Volume Down	1754
Zone 44 Loudness Toggle	1755
Zone 44 Power On Volume Toggle	1756
Zone 44 Mono/Stereo Toggle	1757
Zone 44 Source 1 Select	1735
Zone 44 Source 2 Select	1736
Zone 44 Source 3 Select	1737
Zone 44 Source 4 Select	1738
Zone 44 Source 5 Select	1739
Zone 44 Source 6 Select	1740
Zone 44 Source 7 Select	1741
Zone 44 Source 8 Select	1742
Zone 44 Volume Level	431
Zone 44 Bass Level	432
Zone 44 Treble Level	433
Zone 44 Gain Level	434
Zone 44 Power On Volume Level	435
Zone 44 Balance Level	436
Zone 44 Max Volume Level	437
Zone 44 Zone Name	1734

Function	Channel/Level
Zone 45 Power Toggle	1770
Zone 45 Power On	1798
Zone 45 Power Off	1799
Zone 45 Mute Toggle	1771
Zone 45 Mute On	1800
Zone 45 Mute Off	1801
Zone 45 Volume Up	1772
Zone 45 Volume Down	1773
Zone 45 Bass Up	1783
Zone 45 Bass Down	1784
Zone 45 Treble Up	1785
Zone 45 Treble Down	1786
Zone 45 Gain Up	1787
Zone 45 Gain Down	1788
Zone 45 Power On Volume Up	1789
Zone 45 Power On Volume Down	1790
Zone 45 Balance Left	1791
Zone 45 Balance Right	1792
Zone 45 Max Volume Up	1793
Zone 45 Max Volume Down	1794
Zone 45 Loudness Toggle	1795
Zone 45 Power On Volume Toggle	1796
Zone 45 Mono/Stereo Toggle	1797
Zone 45 Source 1 Select	1775
Zone 45 Source 2 Select	1776
Zone 45 Source 3 Select	1777
Zone 45 Source 4 Select	1778
Zone 45 Source 5 Select	1779
Zone 45 Source 6 Select	1780
Zone 45 Source 7 Select	1781
Zone 45 Source 8 Select	1782
Zone 45 Volume Level	441
Zone 45 Bass Level	442
Zone 45 Treble Level	443
Zone 45 Gain Level	444
Zone 45 Power On Volume Level	445
Zone 45 Balance Level	446
Zone 45 Max Volume Level	447
Zone 45 Zone Name	1774

Function	Channel/Level
Zone 46 Power Toggle	1810
Zone 46 Power On	1838
Zone 46 Power Off	1839
Zone 46 Mute Toggle	1811
Zone 46 Mute On	1840
Zone 46 Mute Off	1841
Zone 46 Volume Up	1812
Zone 46 Volume Down	1813
Zone 46 Bass Up	1823
Zone 46 Bass Down	1824
Zone 46 Treble Up	1825
Zone 46 Treble Down	1826
Zone 46 Gain Up	1827
Zone 46 Gain Down	1828
Zone 46 Power On Volume Up	1829
Zone 46 Power On Volume Down	1830
Zone 46 Balance Left	1831
Zone 46 Balance Right	1832
Zone 46 Max Volume Up	1833
Zone 46 Max Volume Down	1834
Zone 46 Loudness Toggle	1835
Zone 46 Power On Volume Toggle	1836
Zone 46 Mono/Stereo Toggle	1837
Zone 46 Source 1 Select	1815
Zone 46 Source 2 Select	1816
Zone 46 Source 3 Select	1817
Zone 46 Source 4 Select	1818
Zone 46 Source 5 Select	1819
Zone 46 Source 6 Select	1820
Zone 46 Source 7 Select	1821
Zone 46 Source 8 Select	1822
Zone 46 Volume Level	451
Zone 46 Bass Level	452
Zone 46 Treble Level	453
Zone 46 Gain Level	454
Zone 46 Power On Volume Level	455
Zone 46 Balance Level	456
Zone 46 Max Volume Level	457
Zone 46 Zone Name	1814

Function	Channel/Level
Zone 47 Power Toggle	1850
Zone 47 Power On	1878
Zone 47 Power Off	1879
Zone 47 Mute Toggle	1851
Zone 47 Mute On	1880
Zone 47 Mute Off	1881
Zone 47 Volume Up	1852
Zone 47 Volume Down	1853
Zone 47 Bass Up	1863
Zone 47 Bass Down	1864
Zone 47 Treble Up	1865
Zone 47 Treble Down	1866
Zone 47 Gain Up	1867
Zone 47 Gain Down	1868
Zone 47 Power On Volume Up	1869
Zone 47 Power On Volume Down	1870
Zone 47 Balance Left	1871
Zone 47 Balance Right	1872
Zone 47 Max Volume Up	1873
Zone 47 Max Volume Down	1874
Zone 47 Loudness Toggle	1875
Zone 47 Power On Volume Toggle	1876
Zone 47 Mono/Stereo Toggle	1877
Zone 47 Source 1 Select	1855
Zone 47 Source 2 Select	1856
Zone 47 Source 3 Select	1857
Zone 47 Source 4 Select	1858
Zone 47 Source 5 Select	1859
Zone 47 Source 6 Select	1860
Zone 47 Source 7 Select	1861
Zone 47 Source 8 Select	1862
Zone 47 Volume Level	461
Zone 47 Bass Level	462
Zone 47 Treble Level	463
Zone 47 Gain Level	464
Zone 47 Power On Volume Level	465
Zone 47 Balance Level	466
Zone 47 Max Volume Level	467
Zone 47 Zone Name	1854

Function	Channel/Level
Zone 48 Power Toggle	1890
Zone 48 Power On	1918
Zone 48 Power Off	1919
Zone 48 Mute Toggle	1891
Zone 48 Mute On	1920
Zone 48 Mute Off	1921
Zone 48 Volume Up	1892
Zone 48 Volume Down	1893
Zone 48 Bass Up	1903
Zone 48 Bass Down	1904
Zone 48 Treble Up	1905
Zone 48 Treble Down	1906
Zone 48 Gain Up	1907
Zone 48 Gain Down	1908
Zone 48 Power On Volume Up	1909
Zone 48 Power On Volume Down	1910
Zone 48 Balance Left	1911
Zone 48 Balance Right	1912
Zone 48 Max Volume Up	1913
Zone 48 Max Volume Down	1914
Zone 48 Loudness Toggle	1915
Zone 48 Power On Volume Toggle	1916
Zone 48 Mono/Stereo Toggle	1917
Zone 48 Source 1 Select	1895
Zone 48 Source 2 Select	1896
Zone 48 Source 3 Select	1897
Zone 48 Source 4 Select	1898
Zone 48 Source 5 Select	1899
Zone 48 Source 6 Select	1900
Zone 48 Source 7 Select	1901
Zone 48 Source 8 Select	1902
Zone 48 Volume Level	471
Zone 48 Bass Level	472
Zone 48 Treble Level	473
Zone 48 Gain Level	474
Zone 48 Power On Volume Level	475
Zone 48 Balance Level	476
Zone 48 Max Volume Level	477
Zone 48 Zone Name	1894

Function	Channel/Level
Zone 49 Power Toggle	1930
Zone 49 Power On	1958
Zone 49 Power Off	1959
Zone 49 Mute Toggle	1931
Zone 49 Mute On	1960
Zone 49 Mute Off	1961
Zone 49 Volume Up	1932
Zone 49 Volume Down	1933
Zone 49 Bass Up	1943
Zone 49 Bass Down	1944
Zone 49 Treble Up	1945
Zone 49 Treble Down	1946
Zone 49 Gain Up	1947
Zone 49 Gain Down	1948
Zone 49 Power On Volume Up	1949
Zone 49 Power On Volume Down	1950
Zone 49 Balance Left	1951
Zone 49 Balance Right	1952
Zone 49 Max Volume Up	1953
Zone 49 Max Volume Down	1954
Zone 49 Loudness Toggle	1955
Zone 49 Power On Volume Toggle	1956
Zone 49 Mono/Stereo Toggle	1957
Zone 49 Source 1 Select	1935
Zone 49 Source 2 Select	1936
Zone 49 Source 3 Select	1937
Zone 49 Source 4 Select	1938
Zone 49 Source 5 Select	1939
Zone 49 Source 6 Select	1940
Zone 49 Source 7 Select	1941
Zone 49 Source 8 Select	1942
Zone 49 Volume Level	481
Zone 49 Bass Level	482
Zone 49 Treble Level	483
Zone 49 Gain Level	484
Zone 49 Power On Volume Level	485
Zone 49 Balance Level	486
Zone 49 Max Volume Level	487
Zone 49 Zone Name	1934

Function	Channel/Level
Zone 50 Power Toggle	1970
Zone 50 Power On	1998
Zone 50 Power Off	1999
Zone 50 Mute Toggle	1971
Zone 50 Mute On	2000
Zone 50 Mute Off	2001
Zone 50 Volume Up	1972
Zone 50 Volume Down	1973
Zone 50 Bass Up	1983
Zone 50 Bass Down	1984
Zone 50 Treble Up	1985
Zone 50 Treble Down	1986
Zone 50 Gain Up	1987
Zone 50 Gain Down	1988
Zone 50 Power On Volume Up	1989
Zone 50 Power On Volume Down	1990
Zone 50 Balance Left	1991
Zone 50 Balance Right	1992
Zone 50 Max Volume Up	1993
Zone 50 Max Volume Down	1994
Zone 50 Loudness Toggle	1995
Zone 50 Power On Volume Toggle	1996
Zone 50 Mono/Stereo Toggle	1997
Zone 50 Source 1 Select	1975
Zone 50 Source 2 Select	1976
Zone 50 Source 3 Select	1977
Zone 50 Source 4 Select	1978
Zone 50 Source 5 Select	1979
Zone 50 Source 6 Select	1980
Zone 50 Source 7 Select	1981
Zone 50 Source 8 Select	1982
Zone 50 Volume Level	491
Zone 50 Bass Level	492
Zone 50 Treble Level	493
Zone 50 Gain Level	494
Zone 50 Power On Volume Level	495
Zone 50 Balance Level	496
Zone 50 Max Volume Level	497
Zone 50 Zone Name	1974

Function	Channel/Level
Zone 51 Power Toggle	2010
Zone 51 Power On	2038
Zone 51 Power Off	2039
Zone 51 Mute Toggle	2011
Zone 51 Mute On	2040
Zone 51 Mute Off	2041
Zone 51 Volume Up	2012
Zone 51 Volume Down	2013
Zone 51 Bass Up	2023
Zone 51 Bass Down	2024
Zone 51 Treble Up	2025
Zone 51 Treble Down	2026
Zone 51 Gain Up	2027
Zone 51 Gain Down	2028
Zone 51 Power On Volume Up	2029
Zone 51 Power On Volume Down	2030
Zone 51 Balance Left	2031
Zone 51 Balance Right	2032
Zone 51 Max Volume Up	2033
Zone 51 Max Volume Down	2034
Zone 51 Loudness Toggle	2035
Zone 51 Power On Volume Toggle	2036
Zone 51 Mono/Stereo Toggle	2037
Zone 51 Source 1 Select	2015
Zone 51 Source 2 Select	2016
Zone 51 Source 3 Select	2017
Zone 51 Source 4 Select	2018
Zone 51 Source 5 Select	2019
Zone 51 Source 6 Select	2020
Zone 51 Source 7 Select	2021
Zone 51 Source 8 Select	2022
Zone 51 Volume Level	501
Zone 51 Bass Level	502
Zone 51 Treble Level	503
Zone 51 Gain Level	504
Zone 51 Power On Volume Level	505
Zone 51 Balance Level	506
Zone 51 Max Volume Level	507
Zone 51 Zone Name	2014

Function	Channel/Level
Zone 52 Power Toggle	2050
Zone 52 Power On	2078
Zone 52 Power Off	2079
Zone 52 Mute Toggle	2051
Zone 52 Mute On	2080
Zone 52 Mute Off	2081
Zone 52 Volume Up	2052
Zone 52 Volume Down	2053
Zone 52 Bass Up	2063
Zone 52 Bass Down	2064
Zone 52 Treble Up	2065
Zone 52 Treble Down	2066
Zone 52 Gain Up	2067
Zone 52 Gain Down	2068
Zone 52 Power On Volume Up	2069
Zone 52 Power On Volume Down	2070
Zone 52 Balance Left	2071
Zone 52 Balance Right	2072
Zone 52 Max Volume Up	2073
Zone 52 Max Volume Down	2074
Zone 52 Loudness Toggle	2075
Zone 52 Power On Volume Toggle	2076
Zone 52 Mono/Stereo Toggle	2077
Zone 52 Source 1 Select	2055
Zone 52 Source 2 Select	2056
Zone 52 Source 3 Select	2057
Zone 52 Source 4 Select	2058
Zone 52 Source 5 Select	2059
Zone 52 Source 6 Select	2060
Zone 52 Source 7 Select	2061
Zone 52 Source 8 Select	2062
Zone 52 Volume Level	511
Zone 52 Bass Level	512
Zone 52 Treble Level	513
Zone 52 Gain Level	514
Zone 52 Power On Volume Level	515
Zone 52 Balance Level	516
Zone 52 Max Volume Level	517
Zone 52 Zone Name	2054

Function	Channel/Level
Zone 53 Power Toggle	2090
Zone 53 Power On	2118
Zone 53 Power Off	2119
Zone 53 Mute Toggle	2091
Zone 53 Mute On	2120
Zone 53 Mute Off	2121
Zone 53 Volume Up	2092
Zone 53 Volume Down	2093
Zone 53 Bass Up	2103
Zone 53 Bass Down	2104
Zone 53 Treble Up	2105
Zone 53 Treble Down	2106
Zone 53 Gain Up	2107
Zone 53 Gain Down	2108
Zone 53 Power On Volume Up	2109
Zone 53 Power On Volume Down	2110
Zone 53 Balance Left	2111
Zone 53 Balance Right	2112
Zone 53 Max Volume Up	2113
Zone 53 Max Volume Down	2114
Zone 53 Loudness Toggle	2115
Zone 53 Power On Volume Toggle	2116
Zone 53 Mono/Stereo Toggle	2117
Zone 53 Source 1 Select	2095
Zone 53 Source 2 Select	2096
Zone 53 Source 3 Select	2097
Zone 53 Source 4 Select	2098
Zone 53 Source 5 Select	2099
Zone 53 Source 6 Select	2100
Zone 53 Source 7 Select	2101
Zone 53 Source 8 Select	2102
Zone 53 Volume Level	521
Zone 53 Bass Level	522
Zone 53 Treble Level	523
Zone 53 Gain Level	524
Zone 53 Power On Volume Level	525
Zone 53 Balance Level	526
Zone 53 Max Volume Level	527
Zone 53 Zone Name	2094

Function	Channel/Level
Zone 54 Power Toggle	2130
Zone 54 Power On	2158
Zone 54 Power Off	2159
Zone 54 Mute Toggle	2131
Zone 54 Mute On	2160
Zone 54 Mute Off	2161
Zone 54 Volume Up	2132
Zone 54 Volume Down	2133
Zone 54 Bass Up	2143
Zone 54 Bass Down	2144
Zone 54 Treble Up	2145
Zone 54 Treble Down	2146
Zone 54 Gain Up	2147
Zone 54 Gain Down	2148
Zone 54 Power On Volume Up	2149
Zone 54 Power On Volume Down	2150
Zone 54 Balance Left	2151
Zone 54 Balance Right	2152
Zone 54 Max Volume Up	2153
Zone 54 Max Volume Down	2154
Zone 54 Loudness Toggle	2155
Zone 54 Power On Volume Toggle	2156
Zone 54 Mono/Stereo Toggle	2157
Zone 54 Source 1 Select	2135
Zone 54 Source 2 Select	2136
Zone 54 Source 3 Select	2137
Zone 54 Source 4 Select	2138
Zone 54 Source 5 Select	2139
Zone 54 Source 6 Select	2140
Zone 54 Source 7 Select	2141
Zone 54 Source 8 Select	2142
Zone 54 Volume Level	531
Zone 54 Bass Level	532
Zone 54 Treble Level	533
Zone 54 Gain Level	534
Zone 54 Power On Volume Level	535
Zone 54 Balance Level	536
Zone 54 Max Volume Level	537
Zone 54 Zone Name	2134

Function	Channel/Level
Zone 55 Power Toggle	2170
Zone 55 Power On	2198
Zone 55 Power Off	2199
Zone 55 Mute Toggle	2171
Zone 55 Mute On	2200
Zone 55 Mute Off	2201
Zone 55 Volume Up	2172
Zone 55 Volume Down	2173
Zone 55 Bass Up	2183
Zone 55 Bass Down	2184
Zone 55 Treble Up	2185
Zone 55 Treble Down	2186
Zone 55 Gain Up	2187
Zone 55 Gain Down	2188
Zone 55 Power On Volume Up	2189
Zone 55 Power On Volume Down	2190
Zone 55 Balance Left	2191
Zone 55 Balance Right	2192
Zone 55 Max Volume Up	2193
Zone 55 Max Volume Down	2194
Zone 55 Loudness Toggle	2195
Zone 55 Power On Volume Toggle	2196
Zone 55 Mono/Stereo Toggle	2197
Zone 55 Source 1 Select	2175
Zone 55 Source 2 Select	2176
Zone 55 Source 3 Select	2177
Zone 55 Source 4 Select	2178
Zone 55 Source 5 Select	2179
Zone 55 Source 6 Select	2180
Zone 55 Source 7 Select	2181
Zone 55 Source 8 Select	2182
Zone 55 Volume Level	541
Zone 55 Bass Level	542
Zone 55 Treble Level	543
Zone 55 Gain Level	544
Zone 55 Power On Volume Level	545
Zone 55 Balance Level	546
Zone 55 Max Volume Level	547
Zone 55 Zone Name	2174

Function	Channel/Level
Zone 56 Power Toggle	2210
Zone 56 Power On	2238
Zone 56 Power Off	2239
Zone 56 Mute Toggle	2211
Zone 56 Mute On	2240
Zone 56 Mute Off	2241
Zone 56 Volume Up	2212
Zone 56 Volume Down	2213
Zone 56 Bass Up	2223
Zone 56 Bass Down	2224
Zone 56 Treble Up	2225
Zone 56 Treble Down	2226
Zone 56 Gain Up	2227
Zone 56 Gain Down	2228
Zone 56 Power On Volume Up	2229
Zone 56 Power On Volume Down	2230
Zone 56 Balance Left	2231
Zone 56 Balance Right	2232
Zone 56 Max Volume Up	2233
Zone 56 Max Volume Down	2234
Zone 56 Loudness Toggle	2235
Zone 56 Power On Volume Toggle	2236
Zone 56 Mono/Stereo Toggle	2237
Zone 56 Source 1 Select	2215
Zone 56 Source 2 Select	2216
Zone 56 Source 3 Select	2217
Zone 56 Source 4 Select	2218
Zone 56 Source 5 Select	2219
Zone 56 Source 6 Select	2220
Zone 56 Source 7 Select	2221
Zone 56 Source 8 Select	2222
Zone 56 Volume Level	551
Zone 56 Bass Level	552
Zone 56 Treble Level	553
Zone 56 Gain Level	554
Zone 56 Power On Volume Level	555
Zone 56 Balance Level	556
Zone 56 Max Volume Level	557
Zone 56 Zone Name	2214

Function	Channel/Level
Zone 57 Power Toggle	2250
Zone 57 Power On	2278
Zone 57 Power Off	2279
Zone 57 Mute Toggle	2251
Zone 57 Mute On	2280
Zone 57 Mute Off	2281
Zone 57 Volume Up	2252
Zone 57 Volume Down	2253
Zone 57 Bass Up	2263
Zone 57 Bass Down	2264
Zone 57 Treble Up	2265
Zone 57 Treble Down	2266
Zone 57 Gain Up	2267
Zone 57 Gain Down	2268
Zone 57 Power On Volume Up	2269
Zone 57 Power On Volume Down	2270
Zone 57 Balance Left	2271
Zone 57 Balance Right	2272
Zone 57 Max Volume Up	2273
Zone 57 Max Volume Down	2274
Zone 57 Loudness Toggle	2275
Zone 57 Power On Volume Toggle	2276
Zone 57 Mono/Stereo Toggle	2277
Zone 57 Source 1 Select	2255
Zone 57 Source 2 Select	2256
Zone 57 Source 3 Select	2257
Zone 57 Source 4 Select	2258
Zone 57 Source 5 Select	2259
Zone 57 Source 6 Select	2260
Zone 57 Source 7 Select	2261
Zone 57 Source 8 Select	2262
Zone 57 Volume Level	561
Zone 57 Bass Level	562
Zone 57 Treble Level	563
Zone 57 Gain Level	564
Zone 57 Power On Volume Level	565
Zone 57 Balance Level	566
Zone 57 Max Volume Level	567
Zone 57 Zone Name	2254

Function	Channel/Level
Zone 58 Power Toggle	2290
Zone 58 Power On	2318
Zone 58 Power Off	2319
Zone 58 Mute Toggle	2291
Zone 58 Mute On	2320
Zone 58 Mute Off	2321
Zone 58 Volume Up	2292
Zone 58 Volume Down	2293
Zone 58 Bass Up	2303
Zone 58 Bass Down	2304
Zone 58 Treble Up	2305
Zone 58 Treble Down	2306
Zone 58 Gain Up	2307
Zone 58 Gain Down	2308
Zone 58 Power On Volume Up	2309
Zone 58 Power On Volume Down	2310
Zone 58 Balance Left	2311
Zone 58 Balance Right	2312
Zone 58 Max Volume Up	2313
Zone 58 Max Volume Down	2314
Zone 58 Loudness Toggle	2315
Zone 58 Power On Volume Toggle	2316
Zone 58 Mono/Stereo Toggle	2317
Zone 58 Source 1 Select	2295
Zone 58 Source 2 Select	2296
Zone 58 Source 3 Select	2297
Zone 58 Source 4 Select	2298
Zone 58 Source 5 Select	2299
Zone 58 Source 6 Select	2300
Zone 58 Source 7 Select	2301
Zone 58 Source 8 Select	2302
Zone 58 Volume Level	571
Zone 58 Bass Level	572
Zone 58 Treble Level	573
Zone 58 Gain Level	574
Zone 58 Power On Volume Level	575
Zone 58 Balance Level	576
Zone 58 Max Volume Level	577
Zone 58 Zone Name	2294

Function	Channel/Level
Zone 59 Power Toggle	2330
Zone 59 Power On	2358
Zone 59 Power Off	2359
Zone 59 Mute Toggle	2331
Zone 59 Mute On	2360
Zone 59 Mute Off	2361
Zone 59 Volume Up	2332
Zone 59 Volume Down	2333
Zone 59 Bass Up	2343
Zone 59 Bass Down	2344
Zone 59 Treble Up	2345
Zone 59 Treble Down	2346
Zone 59 Gain Up	2347
Zone 59 Gain Down	2348
Zone 59 Power On Volume Up	2349
Zone 59 Power On Volume Down	2350
Zone 59 Balance Left	2351
Zone 59 Balance Right	2352
Zone 59 Max Volume Up	2353
Zone 59 Max Volume Down	2354
Zone 59 Loudness Toggle	2355
Zone 59 Power On Volume Toggle	2356
Zone 59 Mono/Stereo Toggle	2357
Zone 59 Source 1 Select	2335
Zone 59 Source 2 Select	2336
Zone 59 Source 3 Select	2337
Zone 59 Source 4 Select	2338
Zone 59 Source 5 Select	2339
Zone 59 Source 6 Select	2340
Zone 59 Source 7 Select	2341
Zone 59 Source 8 Select	2342
Zone 59 Volume Level	581
Zone 59 Bass Level	582
Zone 59 Treble Level	583
Zone 59 Gain Level	584
Zone 59 Power On Volume Level	585
Zone 59 Balance Level	586
Zone 59 Max Volume Level	587
Zone 59 Zone Name	2334

Function	Channel/Level
Zone 60 Power Toggle	2370
Zone 60 Power On	2398
Zone 60 Power Off	2399
Zone 60 Mute Toggle	2371
Zone 60 Mute On	2400
Zone 60 Mute Off	2401
Zone 60 Volume Up	2372
Zone 60 Volume Down	2373
Zone 60 Bass Up	2383
Zone 60 Bass Down	2384
Zone 60 Treble Up	2385
Zone 60 Treble Down	2386
Zone 60 Gain Up	2387
Zone 60 Gain Down	2388
Zone 60 Power On Volume Up	2389
Zone 60 Power On Volume Down	2390
Zone 60 Balance Left	2391
Zone 60 Balance Right	2392
Zone 60 Max Volume Up	2393
Zone 60 Max Volume Down	2394
Zone 60 Loudness Toggle	2395
Zone 60 Power On Volume Toggle	2396
Zone 60 Mono/Stereo Toggle	2397
Zone 60 Source 1 Select	2375
Zone 60 Source 2 Select	2376
Zone 60 Source 3 Select	2377
Zone 60 Source 4 Select	2378
Zone 60 Source 5 Select	2379
Zone 60 Source 6 Select	2380
Zone 60 Source 7 Select	2381
Zone 60 Source 8 Select	2382
Zone 60 Volume Level	591
Zone 60 Bass Level	592
Zone 60 Treble Level	593
Zone 60 Gain Level	594
Zone 60 Power On Volume Level	595
Zone 60 Balance Level	596
Zone 60 Max Volume Level	597
Zone 60 Zone Name	2374

Function	Channel/Level
Zone 61 Power Toggle	2410
Zone 61 Power On	2438
Zone 61 Power Off	2439
Zone 61 Mute Toggle	2411
Zone 61 Mute On	2440
Zone 61 Mute Off	2441
Zone 61 Volume Up	2412
Zone 61 Volume Down	2413
Zone 61 Bass Up	2423
Zone 61 Bass Down	2424
Zone 61 Treble Up	2425
Zone 61 Treble Down	2426
Zone 61 Gain Up	2427
Zone 61 Gain Down	2428
Zone 61 Power On Volume Up	2429
Zone 61 Power On Volume Down	2430
Zone 61 Balance Left	2431
Zone 61 Balance Right	2432
Zone 61 Max Volume Up	2433
Zone 61 Max Volume Down	2434
Zone 61 Loudness Toggle	2435
Zone 61 Power On Volume Toggle	2436
Zone 61 Mono/Stereo Toggle	2437
Zone 61 Source 1 Select	2415
Zone 61 Source 2 Select	2416
Zone 61 Source 3 Select	2417
Zone 61 Source 4 Select	2418
Zone 61 Source 5 Select	2419
Zone 61 Source 6 Select	2420
Zone 61 Source 7 Select	2421
Zone 61 Source 8 Select	2422
Zone 61 Volume Level	601
Zone 61 Bass Level	602
Zone 61 Treble Level	603
Zone 61 Gain Level	604
Zone 61 Power On Volume Level	605
Zone 61 Balance Level	606
Zone 61 Max Volume Level	607
Zone 61 Zone Name	2414

Function	Channel/Level
Zone 62 Power Toggle	2450
Zone 62 Power On	2478
Zone 62 Power Off	2479
Zone 62 Mute Toggle	2451
Zone 62 Mute On	2480
Zone 62 Mute Off	2481
Zone 62 Volume Up	2452
Zone 62 Volume Down	2453
Zone 62 Bass Up	2463
Zone 62 Bass Down	2464
Zone 62 Treble Up	2465
Zone 62 Treble Down	2466
Zone 62 Gain Up	2467
Zone 62 Gain Down	2468
Zone 62 Power On Volume Up	2469
Zone 62 Power On Volume Down	2470
Zone 62 Balance Left	2471
Zone 62 Balance Right	2472
Zone 62 Max Volume Up	2473
Zone 62 Max Volume Down	2474
Zone 62 Loudness Toggle	2475
Zone 62 Power On Volume Toggle	2476
Zone 62 Mono/Stereo Toggle	2477
Zone 62 Source 1 Select	2455
Zone 62 Source 2 Select	2456
Zone 62 Source 3 Select	2457
Zone 62 Source 4 Select	2458
Zone 62 Source 5 Select	2459
Zone 62 Source 6 Select	2460
Zone 62 Source 7 Select	2461
Zone 62 Source 8 Select	2462
Zone 62 Volume Level	611
Zone 62 Bass Level	612
Zone 62 Treble Level	613
Zone 62 Gain Level	614
Zone 62 Power On Volume Level	615
Zone 62 Balance Level	616
Zone 62 Max Volume Level	617
Zone 62 Zone Name	2454

Function	Channel/Level
Zone 63 Power Toggle	2490
Zone 63 Power On	2518
Zone 63 Power Off	2519
Zone 63 Mute Toggle	2491
Zone 63 Mute On	2520
Zone 63 Mute Off	2521
Zone 63 Volume Up	2492
Zone 63 Volume Down	2493
Zone 63 Bass Up	2503
Zone 63 Bass Down	2504
Zone 63 Treble Up	2505
Zone 63 Treble Down	2506
Zone 63 Gain Up	2507
Zone 63 Gain Down	2508
Zone 63 Power On Volume Up	2509
Zone 63 Power On Volume Down	2510
Zone 63 Balance Left	2511
Zone 63 Balance Right	2512
Zone 63 Max Volume Up	2513
Zone 63 Max Volume Down	2514
Zone 63 Loudness Toggle	2515
Zone 63 Power On Volume Toggle	2516
Zone 63 Mono/Stereo Toggle	2517
Zone 63 Source 1 Select	2495
Zone 63 Source 2 Select	2496
Zone 63 Source 3 Select	2497
Zone 63 Source 4 Select	2498
Zone 63 Source 5 Select	2499
Zone 63 Source 6 Select	2500
Zone 63 Source 7 Select	2501
Zone 63 Source 8 Select	2502
Zone 63 Volume Level	621
Zone 63 Bass Level	622
Zone 63 Treble Level	623
Zone 63 Gain Level	624
Zone 63 Power On Volume Level	625
Zone 63 Balance Level	626
Zone 63 Max Volume Level	627
Zone 63 Zone Name	2494

Function	Channel/Level
Zone 64 Power Toggle	2530
Zone 64 Power On	2558
Zone 64 Power Off	2559
Zone 64 Mute Toggle	2531
Zone 64 Mute On	2560
Zone 64 Mute Off	2561
Zone 64 Volume Up	2532
Zone 64 Volume Down	2533
Zone 64 Bass Up	2543
Zone 64 Bass Down	2544
Zone 64 Treble Up	2545
Zone 64 Treble Down	2546
Zone 64 Gain Up	2547
Zone 64 Gain Down	2548
Zone 64 Power On Volume Up	2549
Zone 64 Power On Volume Down	2550
Zone 64 Balance Left	2551
Zone 64 Balance Right	2552
Zone 64 Max Volume Up	2553
Zone 64 Max Volume Down	2554
Zone 64 Loudness Toggle	2555
Zone 64 Power On Volume Toggle	2556
Zone 64 Mono/Stereo Toggle	2557
Zone 64 Source 1 Select	2535
Zone 64 Source 2 Select	2536
Zone 64 Source 3 Select	2537
Zone 64 Source 4 Select	2538
Zone 64 Source 5 Select	2539
Zone 64 Source 6 Select	2540
Zone 64 Source 7 Select	2541
Zone 64 Source 8 Select	2542
Zone 64 Volume Level	631
Zone 64 Bass Level	632
Zone 64 Treble Level	633
Zone 64 Gain Level	634
Zone 64 Power On Volume Level	635
Zone 64 Balance Level	636
Zone 64 Max Volume Level	637
Zone 64 Zone Name	2534

Function	Channel/Level
Zone 65 Power Toggle	2570
Zone 65 Power On	2598
Zone 65 Power Off	2599
Zone 65 Mute Toggle	2571
Zone 65 Mute On	2600
Zone 65 Mute Off	2601
Zone 65 Volume Up	2572
Zone 65 Volume Down	2573
Zone 65 Bass Up	2583
Zone 65 Bass Down	2584
Zone 65 Treble Up	2585
Zone 65 Treble Down	2586
Zone 65 Gain Up	2587
Zone 65 Gain Down	2588
Zone 65 Power On Volume Up	2589
Zone 65 Power On Volume Down	2590
Zone 65 Balance Left	2591
Zone 65 Balance Right	2592
Zone 65 Max Volume Up	2593
Zone 65 Max Volume Down	2594
Zone 65 Loudness Toggle	2595
Zone 65 Power On Volume Toggle	2596
Zone 65 Mono/Stereo Toggle	2597
Zone 65 Source 1 Select	2575
Zone 65 Source 2 Select	2576
Zone 65 Source 3 Select	2577
Zone 65 Source 4 Select	2578
Zone 65 Source 5 Select	2579
Zone 65 Source 6 Select	2580
Zone 65 Source 7 Select	2581
Zone 65 Source 8 Select	2582
Zone 65 Volume Level	641
Zone 65 Bass Level	642
Zone 65 Treble Level	643
Zone 65 Gain Level	644
Zone 65 Power On Volume Level	645
Zone 65 Balance Level	646
Zone 65 Max Volume Level	647
Zone 65 Zone Name	2574

Function	Channel/Level
Zone 66 Power Toggle	2610
Zone 66 Power On	2638
Zone 66 Power Off	2639
Zone 66 Mute Toggle	2611
Zone 66 Mute On	2640
Zone 66 Mute Off	2641
Zone 66 Volume Up	2612
Zone 66 Volume Down	2613
Zone 66 Bass Up	2623
Zone 66 Bass Down	2624
Zone 66 Treble Up	2625
Zone 66 Treble Down	2626
Zone 66 Gain Up	2627
Zone 66 Gain Down	2628
Zone 66 Power On Volume Up	2629
Zone 66 Power On Volume Down	2630
Zone 66 Balance Left	2631
Zone 66 Balance Right	2632
Zone 66 Max Volume Up	2633
Zone 66 Max Volume Down	2634
Zone 66 Loudness Toggle	2635
Zone 66 Power On Volume Toggle	2636
Zone 66 Mono/Stereo Toggle	2637
Zone 66 Source 1 Select	2615
Zone 66 Source 2 Select	2616
Zone 66 Source 3 Select	2617
Zone 66 Source 4 Select	2618
Zone 66 Source 5 Select	2619
Zone 66 Source 6 Select	2620
Zone 66 Source 7 Select	2621
Zone 66 Source 8 Select	2622
Zone 66 Volume Level	651
Zone 66 Bass Level	652
Zone 66 Treble Level	653
Zone 66 Gain Level	654
Zone 66 Power On Volume Level	655
Zone 66 Balance Level	656
Zone 66 Max Volume Level	657
Zone 66 Zone Name	2614

Function	Channel/Level
Zone 67 Power Toggle	2650
Zone 67 Power On	2678
Zone 67 Power Off	2679
Zone 67 Mute Toggle	2651
Zone 67 Mute On	2680
Zone 67 Mute Off	2681
Zone 67 Volume Up	2652
Zone 67 Volume Down	2653
Zone 67 Bass Up	2663
Zone 67 Bass Down	2664
Zone 67 Treble Up	2665
Zone 67 Treble Down	2666
Zone 67 Gain Up	2667
Zone 67 Gain Down	2668
Zone 67 Power On Volume Up	2669
Zone 67 Power On Volume Down	2670
Zone 67 Balance Left	2671
Zone 67 Balance Right	2672
Zone 67 Max Volume Up	2673
Zone 67 Max Volume Down	2674
Zone 67 Loudness Toggle	2675
Zone 67 Power On Volume Toggle	2676
Zone 67 Mono/Stereo Toggle	2677
Zone 67 Source 1 Select	2655
Zone 67 Source 2 Select	2656
Zone 67 Source 3 Select	2657
Zone 67 Source 4 Select	2658
Zone 67 Source 5 Select	2659
Zone 67 Source 6 Select	2660
Zone 67 Source 7 Select	2661
Zone 67 Source 8 Select	2662
Zone 67 Volume Level	661
Zone 67 Bass Level	662
Zone 67 Treble Level	663
Zone 67 Gain Level	664
Zone 67 Power On Volume Level	665
Zone 67 Balance Level	666
Zone 67 Max Volume Level	667
Zone 67 Zone Name	2654

Function	Channel/Level
Zone 68 Power Toggle	2690
Zone 68 Power On	2718
Zone 68 Power Off	2719
Zone 68 Mute Toggle	2691
Zone 68 Mute On	2720
Zone 68 Mute Off	2721
Zone 68 Volume Up	2692
Zone 68 Volume Down	2693
Zone 68 Bass Up	2703
Zone 68 Bass Down	2704
Zone 68 Treble Up	2705
Zone 68 Treble Down	2706
Zone 68 Gain Up	2707
Zone 68 Gain Down	2708
Zone 68 Power On Volume Up	2709
Zone 68 Power On Volume Down	2710
Zone 68 Balance Left	2711
Zone 68 Balance Right	2712
Zone 68 Max Volume Up	2713
Zone 68 Max Volume Down	2714
Zone 68 Loudness Toggle	2715
Zone 68 Power On Volume Toggle	2716
Zone 68 Mono/Stereo Toggle	2717
Zone 68 Source 1 Select	2695
Zone 68 Source 2 Select	2696
Zone 68 Source 3 Select	2697
Zone 68 Source 4 Select	2698
Zone 68 Source 5 Select	2699
Zone 68 Source 6 Select	2700
Zone 68 Source 7 Select	2701
Zone 68 Source 8 Select	2702
Zone 68 Volume Level	671
Zone 68 Bass Level	672
Zone 68 Treble Level	673
Zone 68 Gain Level	674
Zone 68 Power On Volume Level	675
Zone 68 Balance Level	676
Zone 68 Max Volume Level	677
Zone 68 Zone Name	2694

Function	Channel/Level
Zone 69 Power Toggle	2730
Zone 69 Power On	2758
Zone 69 Power Off	2759
Zone 69 Mute Toggle	2731
Zone 69 Mute On	2760
Zone 69 Mute Off	2761
Zone 69 Volume Up	2732
Zone 69 Volume Down	2733
Zone 69 Bass Up	2743
Zone 69 Bass Down	2744
Zone 69 Treble Up	2745
Zone 69 Treble Down	2746
Zone 69 Gain Up	2747
Zone 69 Gain Down	2748
Zone 69 Power On Volume Up	2749
Zone 69 Power On Volume Down	2750
Zone 69 Balance Left	2751
Zone 69 Balance Right	2752
Zone 69 Max Volume Up	2753
Zone 69 Max Volume Down	2754
Zone 69 Loudness Toggle	2755
Zone 69 Power On Volume Toggle	2756
Zone 69 Mono/Stereo Toggle	2757
Zone 69 Source 1 Select	2735
Zone 69 Source 2 Select	2736
Zone 69 Source 3 Select	2737
Zone 69 Source 4 Select	2738
Zone 69 Source 5 Select	2739
Zone 69 Source 6 Select	2740
Zone 69 Source 7 Select	2741
Zone 69 Source 8 Select	2742
Zone 69 Volume Level	681
Zone 69 Bass Level	682
Zone 69 Treble Level	683
Zone 69 Gain Level	684
Zone 69 Power On Volume Level	685
Zone 69 Balance Level	686
Zone 69 Max Volume Level	687
Zone 69 Zone Name	2734

Function	Channel/Level
Zone 70 Power Toggle	2770
Zone 70 Power On	2798
Zone 70 Power Off	2799
Zone 70 Mute Toggle	2771
Zone 70 Mute On	2800
Zone 70 Mute Off	2801
Zone 70 Volume Up	2772
Zone 70 Volume Down	2773
Zone 70 Bass Up	2783
Zone 70 Bass Down	2784
Zone 70 Treble Up	2785
Zone 70 Treble Down	2786
Zone 70 Gain Up	2787
Zone 70 Gain Down	2788
Zone 70 Power On Volume Up	2789
Zone 70 Power On Volume Down	2790
Zone 70 Balance Left	2791
Zone 70 Balance Right	2792
Zone 70 Max Volume Up	2793
Zone 70 Max Volume Down	2794
Zone 70 Loudness Toggle	2795
Zone 70 Power On Volume Toggle	2796
Zone 70 Mono/Stereo Toggle	2797
Zone 70 Source 1 Select	2775
Zone 70 Source 2 Select	2776
Zone 70 Source 3 Select	2777
Zone 70 Source 4 Select	2778
Zone 70 Source 5 Select	2779
Zone 70 Source 6 Select	2780
Zone 70 Source 7 Select	2781
Zone 70 Source 8 Select	2782
Zone 70 Volume Level	691
Zone 70 Bass Level	692
Zone 70 Treble Level	693
Zone 70 Gain Level	694
Zone 70 Power On Volume Level	695
Zone 70 Balance Level	696
Zone 70 Max Volume Level	697
Zone 70 Zone Name	2774

Function	Channel/Level
Zone 71 Power Toggle	2810
Zone 71 Power On	2838
Zone 71 Power Off	2839
Zone 71 Mute Toggle	2811
Zone 71 Mute On	2840
Zone 71 Mute Off	2841
Zone 71 Volume Up	2812
Zone 71 Volume Down	2813
Zone 71 Bass Up	2823
Zone 71 Bass Down	2824
Zone 71 Treble Up	2825
Zone 71 Treble Down	2826
Zone 71 Gain Up	2827
Zone 71 Gain Down	2828
Zone 71 Power On Volume Up	2829
Zone 71 Power On Volume Down	2830
Zone 71 Balance Left	2831
Zone 71 Balance Right	2832
Zone 71 Max Volume Up	2833
Zone 71 Max Volume Down	2834
Zone 71 Loudness Toggle	2835
Zone 71 Power On Volume Toggle	2836
Zone 71 Mono/Stereo Toggle	2837
Zone 71 Source 1 Select	2815
Zone 71 Source 2 Select	2816
Zone 71 Source 3 Select	2817
Zone 71 Source 4 Select	2818
Zone 71 Source 5 Select	2819
Zone 71 Source 6 Select	2820
Zone 71 Source 7 Select	2821
Zone 71 Source 8 Select	2822
Zone 71 Volume Level	701
Zone 71 Bass Level	702
Zone 71 Treble Level	703
Zone 71 Gain Level	704
Zone 71 Power On Volume Level	705
Zone 71 Balance Level	706
Zone 71 Max Volume Level	707
Zone 71 Zone Name	2814

Function	Channel/Level
Zone 72 Power Toggle	2850
Zone 72 Power On	2878
Zone 72 Power Off	2879
Zone 72 Mute Toggle	2851
Zone 72 Mute On	2880
Zone 72 Mute Off	2881
Zone 72 Volume Up	2852
Zone 72 Volume Down	2853
Zone 72 Bass Up	2863
Zone 72 Bass Down	2864
Zone 72 Treble Up	2865
Zone 72 Treble Down	2866
Zone 72 Gain Up	2867
Zone 72 Gain Down	2868
Zone 72 Power On Volume Up	2869
Zone 72 Power On Volume Down	2870
Zone 72 Balance Left	2871
Zone 72 Balance Right	2872
Zone 72 Max Volume Up	2873
Zone 72 Max Volume Down	2874
Zone 72 Loudness Toggle	2875
Zone 72 Power On Volume Toggle	2876
Zone 72 Mono/Stereo Toggle	2877
Zone 72 Source 1 Select	2855
Zone 72 Source 2 Select	2856
Zone 72 Source 3 Select	2857
Zone 72 Source 4 Select	2858
Zone 72 Source 5 Select	2859
Zone 72 Source 6 Select	2860
Zone 72 Source 7 Select	2861
Zone 72 Source 8 Select	2862
Zone 72 Volume Level	711
Zone 72 Bass Level	712
Zone 72 Treble Level	713
Zone 72 Gain Level	714
Zone 72 Power On Volume Level	715
Zone 72 Balance Level	716
Zone 72 Max Volume Level	717
Zone 72 Zone Name	2854

Function	Channel/Level
Zone 73 Power Toggle	2890
Zone 73 Power On	2918
Zone 73 Power Off	2919
Zone 73 Mute Toggle	2891
Zone 73 Mute On	2920
Zone 73 Mute Off	2921
Zone 73 Volume Up	2892
Zone 73 Volume Down	2893
Zone 73 Bass Up	2903
Zone 73 Bass Down	2904
Zone 73 Treble Up	2905
Zone 73 Treble Down	2906
Zone 73 Gain Up	2907
Zone 73 Gain Down	2908
Zone 73 Power On Volume Up	2909
Zone 73 Power On Volume Down	2910
Zone 73 Balance Left	2911
Zone 73 Balance Right	2912
Zone 73 Max Volume Up	2913
Zone 73 Max Volume Down	2914
Zone 73 Loudness Toggle	2915
Zone 73 Power On Volume Toggle	2916
Zone 73 Mono/Stereo Toggle	2917
Zone 73 Source 1 Select	2895
Zone 73 Source 2 Select	2896
Zone 73 Source 3 Select	2897
Zone 73 Source 4 Select	2898
Zone 73 Source 5 Select	2899
Zone 73 Source 6 Select	2900
Zone 73 Source 7 Select	2901
Zone 73 Source 8 Select	2902
Zone 73 Volume Level	721
Zone 73 Bass Level	722
Zone 73 Treble Level	723
Zone 73 Gain Level	724
Zone 73 Power On Volume Level	725
Zone 73 Balance Level	726
Zone 73 Max Volume Level	727
Zone 73 Zone Name	2894

Function	Channel/Level
Zone 74 Power Toggle	2930
Zone 74 Power On	2958
Zone 74 Power Off	2959
Zone 74 Mute Toggle	2931
Zone 74 Mute On	2960
Zone 74 Mute Off	2961
Zone 74 Volume Up	2932
Zone 74 Volume Down	2933
Zone 74 Bass Up	2943
Zone 74 Bass Down	2944
Zone 74 Treble Up	2945
Zone 74 Treble Down	2946
Zone 74 Gain Up	2947
Zone 74 Gain Down	2948
Zone 74 Power On Volume Up	2949
Zone 74 Power On Volume Down	2950
Zone 74 Balance Left	2951
Zone 74 Balance Right	2952
Zone 74 Max Volume Up	2953
Zone 74 Max Volume Down	2954
Zone 74 Loudness Toggle	2955
Zone 74 Power On Volume Toggle	2956
Zone 74 Mono/Stereo Toggle	2957
Zone 74 Source 1 Select	2935
Zone 74 Source 2 Select	2936
Zone 74 Source 3 Select	2937
Zone 74 Source 4 Select	2938
Zone 74 Source 5 Select	2939
Zone 74 Source 6 Select	2940
Zone 74 Source 7 Select	2941
Zone 74 Source 8 Select	2942
Zone 74 Volume Level	731
Zone 74 Bass Level	732
Zone 74 Treble Level	733
Zone 74 Gain Level	734
Zone 74 Power On Volume Level	735
Zone 74 Balance Level	736
Zone 74 Max Volume Level	737
Zone 74 Zone Name	2934

Function	Channel/Level
Zone 75 Power Toggle	2970
Zone 75 Power On	2998
Zone 75 Power Off	2999
Zone 75 Mute Toggle	2971
Zone 75 Mute On	3000
Zone 75 Mute Off	3001
Zone 75 Volume Up	2972
Zone 75 Volume Down	2973
Zone 75 Bass Up	2983
Zone 75 Bass Down	2984
Zone 75 Treble Up	2985
Zone 75 Treble Down	2986
Zone 75 Gain Up	2987
Zone 75 Gain Down	2988
Zone 75 Power On Volume Up	2989
Zone 75 Power On Volume Down	2990
Zone 75 Balance Left	2991
Zone 75 Balance Right	2992
Zone 75 Max Volume Up	2993
Zone 75 Max Volume Down	2994
Zone 75 Loudness Toggle	2995
Zone 75 Power On Volume Toggle	2996
Zone 75 Mono/Stereo Toggle	2997
Zone 75 Source 1 Select	2975
Zone 75 Source 2 Select	2976
Zone 75 Source 3 Select	2977
Zone 75 Source 4 Select	2978
Zone 75 Source 5 Select	2979
Zone 75 Source 6 Select	2980
Zone 75 Source 7 Select	2981
Zone 75 Source 8 Select	2982
Zone 75 Volume Level	741
Zone 75 Bass Level	742
Zone 75 Treble Level	743
Zone 75 Gain Level	744
Zone 75 Power On Volume Level	745
Zone 75 Balance Level	746
Zone 75 Max Volume Level	747
Zone 75 Zone Name	2974

Function	Channel/Level
Zone 76 Power Toggle	3010
Zone 76 Power On	3038
Zone 76 Power Off	3039
Zone 76 Mute Toggle	3011
Zone 76 Mute On	3040
Zone 76 Mute Off	3041
Zone 76 Volume Up	3012
Zone 76 Volume Down	3013
Zone 76 Bass Up	3023
Zone 76 Bass Down	3024
Zone 76 Treble Up	3025
Zone 76 Treble Down	3026
Zone 76 Gain Up	3027
Zone 76 Gain Down	3028
Zone 76 Power On Volume Up	3029
Zone 76 Power On Volume Down	3030
Zone 76 Balance Left	3031
Zone 76 Balance Right	3032
Zone 76 Max Volume Up	3033
Zone 76 Max Volume Down	3034
Zone 76 Loudness Toggle	3035
Zone 76 Power On Volume Toggle	3036
Zone 76 Mono/Stereo Toggle	3037
Zone 76 Source 1 Select	3015
Zone 76 Source 2 Select	3016
Zone 76 Source 3 Select	3017
Zone 76 Source 4 Select	3018
Zone 76 Source 5 Select	3019
Zone 76 Source 6 Select	3020
Zone 76 Source 7 Select	3021
Zone 76 Source 8 Select	3022
Zone 76 Volume Level	751
Zone 76 Bass Level	752
Zone 76 Treble Level	753
Zone 76 Gain Level	754
Zone 76 Power On Volume Level	755
Zone 76 Balance Level	756
Zone 76 Max Volume Level	757
Zone 76 Zone Name	3014

Function	Channel/Level
Zone 77 Power Toggle	3050
Zone 77 Power On	3078
Zone 77 Power Off	3079
Zone 77 Mute Toggle	3051
Zone 77 Mute On	3080
Zone 77 Mute Off	3081
Zone 77 Volume Up	3052
Zone 77 Volume Down	3053
Zone 77 Bass Up	3063
Zone 77 Bass Down	3064
Zone 77 Treble Up	3065
Zone 77 Treble Down	3066
Zone 77 Gain Up	3067
Zone 77 Gain Down	3068
Zone 77 Power On Volume Up	3069
Zone 77 Power On Volume Down	3070
Zone 77 Balance Left	3071
Zone 77 Balance Right	3072
Zone 77 Max Volume Up	3073
Zone 77 Max Volume Down	3074
Zone 77 Loudness Toggle	3075
Zone 77 Power On Volume Toggle	3076
Zone 77 Mono/Stereo Toggle	3077
Zone 77 Source 1 Select	3055
Zone 77 Source 2 Select	3056
Zone 77 Source 3 Select	3057
Zone 77 Source 4 Select	3058
Zone 77 Source 5 Select	3059
Zone 77 Source 6 Select	3060
Zone 77 Source 7 Select	3061
Zone 77 Source 8 Select	3062
Zone 77 Volume Level	761
Zone 77 Bass Level	762
Zone 77 Treble Level	763
Zone 77 Gain Level	764
Zone 77 Power On Volume Level	765
Zone 77 Balance Level	766
Zone 77 Max Volume Level	767
Zone 77 Zone Name	3054

Function	Channel/Level
Zone 78 Power Toggle	3090
Zone 78 Power On	3118
Zone 78 Power Off	3119
Zone 78 Mute Toggle	3091
Zone 78 Mute On	3120
Zone 78 Mute Off	3121
Zone 78 Volume Up	3092
Zone 78 Volume Down	3093
Zone 78 Bass Up	3103
Zone 78 Bass Down	3104
Zone 78 Treble Up	3105
Zone 78 Treble Down	3106
Zone 78 Gain Up	3107
Zone 78 Gain Down	3108
Zone 78 Power On Volume Up	3109
Zone 78 Power On Volume Down	3110
Zone 78 Balance Left	3111
Zone 78 Balance Right	3112
Zone 78 Max Volume Up	3113
Zone 78 Max Volume Down	3114
Zone 78 Loudness Toggle	3115
Zone 78 Power On Volume Toggle	3116
Zone 78 Mono/Stereo Toggle	3117
Zone 78 Source 1 Select	3095
Zone 78 Source 2 Select	3096
Zone 78 Source 3 Select	3097
Zone 78 Source 4 Select	3098
Zone 78 Source 5 Select	3099
Zone 78 Source 6 Select	3100
Zone 78 Source 7 Select	3101
Zone 78 Source 8 Select	3102
Zone 78 Volume Level	771
Zone 78 Bass Level	772
Zone 78 Treble Level	773
Zone 78 Gain Level	774
Zone 78 Power On Volume Level	775
Zone 78 Balance Level	776
Zone 78 Max Volume Level	777
Zone 78 Zone Name	3094

Function	Channel/Level
Zone 79 Power Toggle	3130
Zone 79 Power On	3158
Zone 79 Power Off	3159
Zone 79 Mute Toggle	3131
Zone 79 Mute On	3160
Zone 79 Mute Off	3161
Zone 79 Volume Up	3132
Zone 79 Volume Down	3133
Zone 79 Bass Up	3143
Zone 79 Bass Down	3144
Zone 79 Treble Up	3145
Zone 79 Treble Down	3146
Zone 79 Gain Up	3147
Zone 79 Gain Down	3148
Zone 79 Power On Volume Up	3149
Zone 79 Power On Volume Down	3150
Zone 79 Balance Left	3151
Zone 79 Balance Right	3152
Zone 79 Max Volume Up	3153
Zone 79 Max Volume Down	3154
Zone 79 Loudness Toggle	3155
Zone 79 Power On Volume Toggle	3156
Zone 79 Mono/Stereo Toggle	3157
Zone 79 Source 1 Select	3135
Zone 79 Source 2 Select	3136
Zone 79 Source 3 Select	3137
Zone 79 Source 4 Select	3138
Zone 79 Source 5 Select	3139
Zone 79 Source 6 Select	3140
Zone 79 Source 7 Select	3141
Zone 79 Source 8 Select	3142
Zone 79 Volume Level	781
Zone 79 Bass Level	782
Zone 79 Treble Level	783
Zone 79 Gain Level	784
Zone 79 Power On Volume Level	785
Zone 79 Balance Level	786
Zone 79 Max Volume Level	787
Zone 79 Zone Name	3134

Function	Channel/Level
Zone 80 Power Toggle	3170
Zone 80 Power On	3198
Zone 80 Power Off	3199
Zone 80 Mute Toggle	3171
Zone 80 Mute On	3200
Zone 80 Mute Off	3201
Zone 80 Volume Up	3172
Zone 80 Volume Down	3173
Zone 80 Bass Up	3183
Zone 80 Bass Down	3184
Zone 80 Treble Up	3185
Zone 80 Treble Down	3186
Zone 80 Gain Up	3187
Zone 80 Gain Down	3188
Zone 80 Power On Volume Up	3189
Zone 80 Power On Volume Down	3190
Zone 80 Balance Left	3191
Zone 80 Balance Right	3192
Zone 80 Max Volume Up	3193
Zone 80 Max Volume Down	3194
Zone 80 Loudness Toggle	3195
Zone 80 Power On Volume Toggle	3196
Zone 80 Mono/Stereo Toggle	3197
Zone 80 Source 1 Select	3175
Zone 80 Source 2 Select	3176
Zone 80 Source 3 Select	3177
Zone 80 Source 4 Select	3178
Zone 80 Source 5 Select	3179
Zone 80 Source 6 Select	3180
Zone 80 Source 7 Select	3181
Zone 80 Source 8 Select	3182
Zone 80 Volume Level	791
Zone 80 Bass Level	792
Zone 80 Treble Level	793
Zone 80 Gain Level	794
Zone 80 Power On Volume Level	795
Zone 80 Balance Level	796
Zone 80 Max Volume Level	797
Zone 80 Zone Name	3174

Function	Channel/Level
Zone 81 Power Toggle	3210
Zone 81 Power On	3238
Zone 81 Power Off	3239
Zone 81 Mute Toggle	3211
Zone 81 Mute On	3240
Zone 81 Mute Off	3241
Zone 81 Volume Up	3212
Zone 81 Volume Down	3213
Zone 81 Bass Up	3223
Zone 81 Bass Down	3224
Zone 81 Treble Up	3225
Zone 81 Treble Down	3226
Zone 81 Gain Up	3227
Zone 81 Gain Down	3228
Zone 81 Power On Volume Up	3229
Zone 81 Power On Volume Down	3230
Zone 81 Balance Left	3231
Zone 81 Balance Right	3232
Zone 81 Max Volume Up	3233
Zone 81 Max Volume Down	3234
Zone 81 Loudness Toggle	3235
Zone 81 Power On Volume Toggle	3236
Zone 81 Mono/Stereo Toggle	3237
Zone 81 Source 1 Select	3215
Zone 81 Source 2 Select	3216
Zone 81 Source 3 Select	3217
Zone 81 Source 4 Select	3218
Zone 81 Source 5 Select	3219
Zone 81 Source 6 Select	3220
Zone 81 Source 7 Select	3221
Zone 81 Source 8 Select	3222
Zone 81 Volume Level	801
Zone 81 Bass Level	802
Zone 81 Treble Level	803
Zone 81 Gain Level	804
Zone 81 Power On Volume Level	805
Zone 81 Balance Level	806
Zone 81 Max Volume Level	807
Zone 81 Zone Name	3214

Function	Channel/Level
Zone 82 Power Toggle	3250
Zone 82 Power On	3278
Zone 82 Power Off	3279
Zone 82 Mute Toggle	3251
Zone 82 Mute On	3280
Zone 82 Mute Off	3281
Zone 82 Volume Up	3252
Zone 82 Volume Down	3253
Zone 82 Bass Up	3263
Zone 82 Bass Down	3264
Zone 82 Treble Up	3265
Zone 82 Treble Down	3266
Zone 82 Gain Up	3267
Zone 82 Gain Down	3268
Zone 82 Power On Volume Up	3269
Zone 82 Power On Volume Down	3270
Zone 82 Balance Left	3271
Zone 82 Balance Right	3272
Zone 82 Max Volume Up	3273
Zone 82 Max Volume Down	3274
Zone 82 Loudness Toggle	3275
Zone 82 Power On Volume Toggle	3276
Zone 82 Mono/Stereo Toggle	3277
Zone 82 Source 1 Select	3255
Zone 82 Source 2 Select	3256
Zone 82 Source 3 Select	3257
Zone 82 Source 4 Select	3258
Zone 82 Source 5 Select	3259
Zone 82 Source 6 Select	3260
Zone 82 Source 7 Select	3261
Zone 82 Source 8 Select	3262
Zone 82 Volume Level	811
Zone 82 Bass Level	812
Zone 82 Treble Level	813
Zone 82 Gain Level	814
Zone 82 Power On Volume Level	815
Zone 82 Balance Level	816
Zone 82 Max Volume Level	817
Zone 82 Zone Name	3254

Function	Channel/Level
Zone 83 Power Toggle	3290
Zone 83 Power On	3318
Zone 83 Power Off	3319
Zone 83 Mute Toggle	3291
Zone 83 Mute On	3320
Zone 83 Mute Off	3321
Zone 83 Volume Up	3292
Zone 83 Volume Down	3293
Zone 83 Bass Up	3303
Zone 83 Bass Down	3304
Zone 83 Treble Up	3305
Zone 83 Treble Down	3306
Zone 83 Gain Up	3307
Zone 83 Gain Down	3308
Zone 83 Power On Volume Up	3309
Zone 83 Power On Volume Down	3310
Zone 83 Balance Left	3311
Zone 83 Balance Right	3312
Zone 83 Max Volume Up	3313
Zone 83 Max Volume Down	3314
Zone 83 Loudness Toggle	3315
Zone 83 Power On Volume Toggle	3316
Zone 83 Mono/Stereo Toggle	3317
Zone 83 Source 1 Select	3295
Zone 83 Source 2 Select	3296
Zone 83 Source 3 Select	3297
Zone 83 Source 4 Select	3298
Zone 83 Source 5 Select	3299
Zone 83 Source 6 Select	3300
Zone 83 Source 7 Select	3301
Zone 83 Source 8 Select	3302
Zone 83 Volume Level	821
Zone 83 Bass Level	822
Zone 83 Treble Level	823
Zone 83 Gain Level	824
Zone 83 Power On Volume Level	825
Zone 83 Balance Level	826
Zone 83 Max Volume Level	827
Zone 83 Zone Name	3294

Function	Channel/Level
Zone 84 Power Toggle	3330
Zone 84 Power On	3358
Zone 84 Power Off	3359
Zone 84 Mute Toggle	3331
Zone 84 Mute On	3360
Zone 84 Mute Off	3361
Zone 84 Volume Up	3332
Zone 84 Volume Down	3333
Zone 84 Bass Up	3343
Zone 84 Bass Down	3344
Zone 84 Treble Up	3345
Zone 84 Treble Down	3346
Zone 84 Gain Up	3347
Zone 84 Gain Down	3348
Zone 84 Power On Volume Up	3349
Zone 84 Power On Volume Down	3350
Zone 84 Balance Left	3351
Zone 84 Balance Right	3352
Zone 84 Max Volume Up	3353
Zone 84 Max Volume Down	3354
Zone 84 Loudness Toggle	3355
Zone 84 Power On Volume Toggle	3356
Zone 84 Mono/Stereo Toggle	3357
Zone 84 Source 1 Select	3335
Zone 84 Source 2 Select	3336
Zone 84 Source 3 Select	3337
Zone 84 Source 4 Select	3338
Zone 84 Source 5 Select	3339
Zone 84 Source 6 Select	3340
Zone 84 Source 7 Select	3341
Zone 84 Source 8 Select	3342
Zone 84 Volume Level	831
Zone 84 Bass Level	832
Zone 84 Treble Level	833
Zone 84 Gain Level	834
Zone 84 Power On Volume Level	835
Zone 84 Balance Level	836
Zone 84 Max Volume Level	837
Zone 84 Zone Name	3334

Function	Channel/Level
Zone 85 Power Toggle	3370
Zone 85 Power On	3398
Zone 85 Power Off	3399
Zone 85 Mute Toggle	3371
Zone 85 Mute On	3400
Zone 85 Mute Off	3401
Zone 85 Volume Up	3372
Zone 85 Volume Down	3373
Zone 85 Bass Up	3383
Zone 85 Bass Down	3384
Zone 85 Treble Up	3385
Zone 85 Treble Down	3386
Zone 85 Gain Up	3387
Zone 85 Gain Down	3388
Zone 85 Power On Volume Up	3389
Zone 85 Power On Volume Down	3390
Zone 85 Balance Left	3391
Zone 85 Balance Right	3392
Zone 85 Max Volume Up	3393
Zone 85 Max Volume Down	3394
Zone 85 Loudness Toggle	3395
Zone 85 Power On Volume Toggle	3396
Zone 85 Mono/Stereo Toggle	3397
Zone 85 Source 1 Select	3375
Zone 85 Source 2 Select	3376
Zone 85 Source 3 Select	3377
Zone 85 Source 4 Select	3378
Zone 85 Source 5 Select	3379
Zone 85 Source 6 Select	3380
Zone 85 Source 7 Select	3381
Zone 85 Source 8 Select	3382
Zone 85 Volume Level	841
Zone 85 Bass Level	842
Zone 85 Treble Level	843
Zone 85 Gain Level	844
Zone 85 Power On Volume Level	845
Zone 85 Balance Level	846
Zone 85 Max Volume Level	847
Zone 85 Zone Name	3374

Function	Channel/Level
Zone 86 Power Toggle	3410
Zone 86 Power On	3438
Zone 86 Power Off	3439
Zone 86 Mute Toggle	3411
Zone 86 Mute On	3440
Zone 86 Mute Off	3441
Zone 86 Volume Up	3412
Zone 86 Volume Down	3413
Zone 86 Bass Up	3423
Zone 86 Bass Down	3424
Zone 86 Treble Up	3425
Zone 86 Treble Down	3426
Zone 86 Gain Up	3427
Zone 86 Gain Down	3428
Zone 86 Power On Volume Up	3429
Zone 86 Power On Volume Down	3430
Zone 86 Balance Left	3431
Zone 86 Balance Right	3432
Zone 86 Max Volume Up	3433
Zone 86 Max Volume Down	3434
Zone 86 Loudness Toggle	3435
Zone 86 Power On Volume Toggle	3436
Zone 86 Mono/Stereo Toggle	3437
Zone 86 Source 1 Select	3415
Zone 86 Source 2 Select	3416
Zone 86 Source 3 Select	3417
Zone 86 Source 4 Select	3418
Zone 86 Source 5 Select	3419
Zone 86 Source 6 Select	3420
Zone 86 Source 7 Select	3421
Zone 86 Source 8 Select	3422
Zone 86 Volume Level	851
Zone 86 Bass Level	852
Zone 86 Treble Level	853
Zone 86 Gain Level	854
Zone 86 Power On Volume Level	855
Zone 86 Balance Level	856
Zone 86 Max Volume Level	857
Zone 86 Zone Name	3414

Function	Channel/Level
Zone 87 Power Toggle	3450
Zone 87 Power On	3478
Zone 87 Power Off	3479
Zone 87 Mute Toggle	3451
Zone 87 Mute On	3480
Zone 87 Mute Off	3481
Zone 87 Volume Up	3452
Zone 87 Volume Down	3453
Zone 87 Bass Up	3463
Zone 87 Bass Down	3464
Zone 87 Treble Up	3465
Zone 87 Treble Down	3466
Zone 87 Gain Up	3467
Zone 87 Gain Down	3468
Zone 87 Power On Volume Up	3469
Zone 87 Power On Volume Down	3470
Zone 87 Balance Left	3471
Zone 87 Balance Right	3472
Zone 87 Max Volume Up	3473
Zone 87 Max Volume Down	3474
Zone 87 Loudness Toggle	3475
Zone 87 Power On Volume Toggle	3476
Zone 87 Mono/Stereo Toggle	3477
Zone 87 Source 1 Select	3455
Zone 87 Source 2 Select	3456
Zone 87 Source 3 Select	3457
Zone 87 Source 4 Select	3458
Zone 87 Source 5 Select	3459
Zone 87 Source 6 Select	3460
Zone 87 Source 7 Select	3461
Zone 87 Source 8 Select	3462
Zone 87 Volume Level	861
Zone 87 Bass Level	862
Zone 87 Treble Level	863
Zone 87 Gain Level	864
Zone 87 Power On Volume Level	865
Zone 87 Balance Level	866
Zone 87 Max Volume Level	867
Zone 87 Zone Name	3454

Function	Channel/Level
Zone 88 Power Toggle	3490
Zone 88 Power On	3518
Zone 88 Power Off	3519
Zone 88 Mute Toggle	3491
Zone 88 Mute On	3520
Zone 88 Mute Off	3521
Zone 88 Volume Up	3492
Zone 88 Volume Down	3493
Zone 88 Bass Up	3503
Zone 88 Bass Down	3504
Zone 88 Treble Up	3505
Zone 88 Treble Down	3506
Zone 88 Gain Up	3507
Zone 88 Gain Down	3508
Zone 88 Power On Volume Up	3509
Zone 88 Power On Volume Down	3510
Zone 88 Balance Left	3511
Zone 88 Balance Right	3512
Zone 88 Max Volume Up	3513
Zone 88 Max Volume Down	3514
Zone 88 Loudness Toggle	3515
Zone 88 Power On Volume Toggle	3516
Zone 88 Mono/Stereo Toggle	3517
Zone 88 Source 1 Select	3495
Zone 88 Source 2 Select	3496
Zone 88 Source 3 Select	3497
Zone 88 Source 4 Select	3498
Zone 88 Source 5 Select	3499
Zone 88 Source 6 Select	3500
Zone 88 Source 7 Select	3501
Zone 88 Source 8 Select	3502
Zone 88 Volume Level	871
Zone 88 Bass Level	872
Zone 88 Treble Level	873
Zone 88 Gain Level	874
Zone 88 Power On Volume Level	875
Zone 88 Balance Level	876
Zone 88 Max Volume Level	877
Zone 88 Zone Name	3494

Function	Channel/Level
Zone 89 Power Toggle	3530
Zone 89 Power On	3558
Zone 89 Power Off	3559
Zone 89 Mute Toggle	3531
Zone 89 Mute On	3560
Zone 89 Mute Off	3561
Zone 89 Volume Up	3532
Zone 89 Volume Down	3533
Zone 89 Bass Up	3543
Zone 89 Bass Down	3544
Zone 89 Treble Up	3545
Zone 89 Treble Down	3546
Zone 89 Gain Up	3547
Zone 89 Gain Down	3548
Zone 89 Power On Volume Up	3549
Zone 89 Power On Volume Down	3550
Zone 89 Balance Left	3551
Zone 89 Balance Right	3552
Zone 89 Max Volume Up	3553
Zone 89 Max Volume Down	3554
Zone 89 Loudness Toggle	3555
Zone 89 Power On Volume Toggle	3556
Zone 89 Mono/Stereo Toggle	3557
Zone 89 Source 1 Select	3535
Zone 89 Source 2 Select	3536
Zone 89 Source 3 Select	3537
Zone 89 Source 4 Select	3538
Zone 89 Source 5 Select	3539
Zone 89 Source 6 Select	3540
Zone 89 Source 7 Select	3541
Zone 89 Source 8 Select	3542
Zone 89 Volume Level	881
Zone 89 Bass Level	882
Zone 89 Treble Level	883
Zone 89 Gain Level	884
Zone 89 Power On Volume Level	885
Zone 89 Balance Level	886
Zone 89 Max Volume Level	887
Zone 89 Zone Name	3534

Function	Channel/Level
Zone 90 Power Toggle	3570
Zone 90 Power On	3598
Zone 90 Power Off	3599
Zone 90 Mute Toggle	3571
Zone 90 Mute On	3600
Zone 90 Mute Off	3601
Zone 90 Volume Up	3572
Zone 90 Volume Down	3573
Zone 90 Bass Up	3583
Zone 90 Bass Down	3584
Zone 90 Treble Up	3585
Zone 90 Treble Down	3586
Zone 90 Gain Up	3587
Zone 90 Gain Down	3588
Zone 90 Power On Volume Up	3589
Zone 90 Power On Volume Down	3590
Zone 90 Balance Left	3591
Zone 90 Balance Right	3592
Zone 90 Max Volume Up	3593
Zone 90 Max Volume Down	3594
Zone 90 Loudness Toggle	3595
Zone 90 Power On Volume Toggle	3596
Zone 90 Mono/Stereo Toggle	3597
Zone 90 Source 1 Select	3575
Zone 90 Source 2 Select	3576
Zone 90 Source 3 Select	3577
Zone 90 Source 4 Select	3578
Zone 90 Source 5 Select	3579
Zone 90 Source 6 Select	3580
Zone 90 Source 7 Select	3581
Zone 90 Source 8 Select	3582
Zone 90 Volume Level	891
Zone 90 Bass Level	892
Zone 90 Treble Level	893
Zone 90 Gain Level	894
Zone 90 Power On Volume Level	895
Zone 90 Balance Level	896
Zone 90 Max Volume Level	897
Zone 90 Zone Name	3574

Function	Channel/Level
Zone 91 Power Toggle	3610
Zone 91 Power On	3638
Zone 91 Power Off	3639
Zone 91 Mute Toggle	3611
Zone 91 Mute On	3640
Zone 91 Mute Off	3641
Zone 91 Volume Up	3612
Zone 91 Volume Down	3613
Zone 91 Bass Up	3623
Zone 91 Bass Down	3624
Zone 91 Treble Up	3625
Zone 91 Treble Down	3626
Zone 91 Gain Up	3627
Zone 91 Gain Down	3628
Zone 91 Power On Volume Up	3629
Zone 91 Power On Volume Down	3630
Zone 91 Balance Left	3631
Zone 91 Balance Right	3632
Zone 91 Max Volume Up	3633
Zone 91 Max Volume Down	3634
Zone 91 Loudness Toggle	3635
Zone 91 Power On Volume Toggle	3636
Zone 91 Mono/Stereo Toggle	3637
Zone 91 Source 1 Select	3615
Zone 91 Source 2 Select	3616
Zone 91 Source 3 Select	3617
Zone 91 Source 4 Select	3618
Zone 91 Source 5 Select	3619
Zone 91 Source 6 Select	3620
Zone 91 Source 7 Select	3621
Zone 91 Source 8 Select	3622
Zone 91 Volume Level	901
Zone 91 Bass Level	902
Zone 91 Treble Level	903
Zone 91 Gain Level	904
Zone 91 Power On Volume Level	905
Zone 91 Balance Level	906
Zone 91 Max Volume Level	907
Zone 91 Zone Name	3614

Function	Channel/Level
Zone 92 Power Toggle	3650
Zone 92 Power On	3678
Zone 92 Power Off	3679
Zone 92 Mute Toggle	3651
Zone 92 Mute On	3680
Zone 92 Mute Off	3681
Zone 92 Volume Up	3652
Zone 92 Volume Down	3653
Zone 92 Bass Up	3663
Zone 92 Bass Down	3664
Zone 92 Treble Up	3665
Zone 92 Treble Down	3666
Zone 92 Gain Up	3667
Zone 92 Gain Down	3668
Zone 92 Power On Volume Up	3669
Zone 92 Power On Volume Down	3670
Zone 92 Balance Left	3671
Zone 92 Balance Right	3672
Zone 92 Max Volume Up	3673
Zone 92 Max Volume Down	3674
Zone 92 Loudness Toggle	3675
Zone 92 Power On Volume Toggle	3676
Zone 92 Mono/Stereo Toggle	3677
Zone 92 Source 1 Select	3655
Zone 92 Source 2 Select	3656
Zone 92 Source 3 Select	3657
Zone 92 Source 4 Select	3658
Zone 92 Source 5 Select	3659
Zone 92 Source 6 Select	3660
Zone 92 Source 7 Select	3661
Zone 92 Source 8 Select	3662
Zone 92 Volume Level	911
Zone 92 Bass Level	912
Zone 92 Treble Level	913
Zone 92 Gain Level	914
Zone 92 Power On Volume Level	915
Zone 92 Balance Level	916
Zone 92 Max Volume Level	917
Zone 92 Zone Name	3654

Function	Channel/Level
Zone 93 Power Toggle	3690
Zone 93 Power On	3718
Zone 93 Power Off	3719
Zone 93 Mute Toggle	3691
Zone 93 Mute On	3720
Zone 93 Mute Off	3721
Zone 93 Volume Up	3692
Zone 93 Volume Down	3693
Zone 93 Bass Up	3703
Zone 93 Bass Down	3704
Zone 93 Treble Up	3705
Zone 93 Treble Down	3706
Zone 93 Gain Up	3707
Zone 93 Gain Down	3708
Zone 93 Power On Volume Up	3709
Zone 93 Power On Volume Down	3710
Zone 93 Balance Left	3711
Zone 93 Balance Right	3712
Zone 93 Max Volume Up	3713
Zone 93 Max Volume Down	3714
Zone 93 Loudness Toggle	3715
Zone 93 Power On Volume Toggle	3716
Zone 93 Mono/Stereo Toggle	3717
Zone 93 Source 1 Select	3695
Zone 93 Source 2 Select	3696
Zone 93 Source 3 Select	3697
Zone 93 Source 4 Select	3698
Zone 93 Source 5 Select	3699
Zone 93 Source 6 Select	3700
Zone 93 Source 7 Select	3701
Zone 93 Source 8 Select	3702
Zone 93 Volume Level	921
Zone 93 Bass Level	922
Zone 93 Treble Level	923
Zone 93 Gain Level	924
Zone 93 Power On Volume Level	925
Zone 93 Balance Level	926
Zone 93 Max Volume Level	927
Zone 93 Zone Name	3694

Function	Channel/Level
Zone 94 Power Toggle	3730
Zone 94 Power On	3758
Zone 94 Power Off	3759
Zone 94 Mute Toggle	3731
Zone 94 Mute On	3760
Zone 94 Mute Off	3761
Zone 94 Volume Up	3732
Zone 94 Volume Down	3733
Zone 94 Bass Up	3743
Zone 94 Bass Down	3744
Zone 94 Treble Up	3745
Zone 94 Treble Down	3746
Zone 94 Gain Up	3747
Zone 94 Gain Down	3748
Zone 94 Power On Volume Up	3749
Zone 94 Power On Volume Down	3750
Zone 94 Balance Left	3751
Zone 94 Balance Right	3752
Zone 94 Max Volume Up	3753
Zone 94 Max Volume Down	3754
Zone 94 Loudness Toggle	3755
Zone 94 Power On Volume Toggle	3756
Zone 94 Mono/Stereo Toggle	3757
Zone 94 Source 1 Select	3735
Zone 94 Source 2 Select	3736
Zone 94 Source 3 Select	3737
Zone 94 Source 4 Select	3738
Zone 94 Source 5 Select	3739
Zone 94 Source 6 Select	3740
Zone 94 Source 7 Select	3741
Zone 94 Source 8 Select	3742
Zone 94 Volume Level	931
Zone 94 Bass Level	932
Zone 94 Treble Level	933
Zone 94 Gain Level	934
Zone 94 Power On Volume Level	935
Zone 94 Balance Level	936
Zone 94 Max Volume Level	937
Zone 94 Zone Name	3734

Function	Channel/Level
Zone 95 Power Toggle	3770
Zone 95 Power On	3798
Zone 95 Power Off	3799
Zone 95 Mute Toggle	3771
Zone 95 Mute On	3800
Zone 95 Mute Off	3801
Zone 95 Volume Up	3772
Zone 95 Volume Down	3773
Zone 95 Bass Up	3783
Zone 95 Bass Down	3784
Zone 95 Treble Up	3785
Zone 95 Treble Down	3786
Zone 95 Gain Up	3787
Zone 95 Gain Down	3788
Zone 95 Power On Volume Up	3789
Zone 95 Power On Volume Down	3790
Zone 95 Balance Left	3791
Zone 95 Balance Right	3792
Zone 95 Max Volume Up	3793
Zone 95 Max Volume Down	3794
Zone 95 Loudness Toggle	3795
Zone 95 Power On Volume Toggle	3796
Zone 95 Mono/Stereo Toggle	3797
Zone 95 Source 1 Select	3775
Zone 95 Source 2 Select	3776
Zone 95 Source 3 Select	3777
Zone 95 Source 4 Select	3778
Zone 95 Source 5 Select	3779
Zone 95 Source 6 Select	3780
Zone 95 Source 7 Select	3781
Zone 95 Source 8 Select	3782
Zone 95 Volume Level	941
Zone 95 Bass Level	942
Zone 95 Treble Level	943
Zone 95 Gain Level	944
Zone 95 Power On Volume Level	945
Zone 95 Balance Level	946
Zone 95 Max Volume Level	947
Zone 95 Zone Name	3774

Function	Channel/Level
Zone 96 Power Toggle	3810
Zone 96 Power On	3838
Zone 96 Power Off	3839
Zone 96 Mute Toggle	3811
Zone 96 Mute On	3840
Zone 96 Mute Off	3841
Zone 96 Volume Up	3812
Zone 96 Volume Down	3813
Zone 96 Bass Up	3823
Zone 96 Bass Down	3824
Zone 96 Treble Up	3825
Zone 96 Treble Down	3826
Zone 96 Gain Up	3827
Zone 96 Gain Down	3828
Zone 96 Power On Volume Up	3829
Zone 96 Power On Volume Down	3830
Zone 96 Balance Left	3831
Zone 96 Balance Right	3832
Zone 96 Max Volume Up	3833
Zone 96 Max Volume Down	3834
Zone 96 Loudness Toggle	3835
Zone 96 Power On Volume Toggle	3836
Zone 96 Mono/Stereo Toggle	3837
Zone 96 Source 1 Select	3815
Zone 96 Source 2 Select	3816
Zone 96 Source 3 Select	3817
Zone 96 Source 4 Select	3818
Zone 96 Source 5 Select	3819
Zone 96 Source 6 Select	3820
Zone 96 Source 7 Select	3821
Zone 96 Source 8 Select	3822
Zone 96 Volume Level	951
Zone 96 Bass Level	952
Zone 96 Treble Level	953
Zone 96 Gain Level	954
Zone 96 Power On Volume Level	955
Zone 96 Balance Level	956
Zone 96 Max Volume Level	957
Zone 96 Zone Name	3814